Sub: Standard procedure for providing earthing.

1. Earthing should be provided for different kind of applications as follows:

Transformer - Two earthing and one neutral

Panel boards - One neutral must be provided for one electrical room.

One earthing must be provided for each panel board with

Date: 05.04.2017

a minimum of two earthings per electrical room.

Lifts - One earthing and one neutral per lift.

Generator - Two earthings and one neutral (optional) per generator.

Feeder boxes in villas - One earthing for each feeder box.

Generator feeder box - Nil. Connect to main feeder box earthing.

in villas

Within villas - One earthing

- 2. Each earthing and neutral should be of 6' x 2' x 2'. Use a 5' 6" GI pipe of 2"dia B class connected to a 1'x 1' 3 mm thick copper plate at its bottom. After placing the GI pipe and copper plate fill the earth pit with alternate layers of earth, sand and bentonite powder. Use a large gampa of each material for each layer. Approximately each layer would be about 2". In the last 1' install a 2' CC ring with a 2" RCC cover. The RCC cover should have an opening of 9" x 12" covered with a CC gully trap cover. The filling of the pit should be 3" below the RCC cover. The GI pipe must be clearly visible.
- 3. The earth pit must be connected to the panel/generator/transformer, etc., with a 25 x 6 mm GI flat. Flat must be connected of GI pipe with a clamp placed 6" below the top of the pipe. However, in case of neutral for transformer use a 25 x 3mm copper flat. In case of lift neutral an 8 gauge (4 mm) copper wire can be used in place of a GI flat. The inter connects must be buried a foot under the ground to prevent theft.
- 4. In case of villas provide earthing on the rear side of the villa and bolt the GI strip to the nearest wall at a height of 6" above the finished floor level. From there connect with a 7/20 copper wire to the DB.
- 5. Pit must be watered periodically.
- 6. In case of neutral for transformer, use a CI pipe of 3"dia in place of the GI pipe and the copper plate.
- 7. Do not use salt, coal or any other procedure for making earth pits. Make as per drawing enclosed herein.
- 8. The earth pits and neutral pits should be spaced at a distance of 10' from each other.
- 9. Testing: the voltage between neutral and earth should be less than 4 volts. In case the voltage is more than 4 volts then the following steps should be taken.
  - a. Water the earth pit about 50 to 100 ltrs of water. Test after one day. If the voltage still remains high, then:
  - b. Add 25 kgs salt to 100 ltrs of water to produce brine. Pour the brine slowly into the earth pit. Wait for 2 days and check voltage. If the voltage still remains high, then:
  - c. Check all connections and if there is no error in connections then earth pit has to be remade at alternate location.
- 10. Relevant drawing is attached in circular 889(a) as figure no. 15