Stop further work. Proceed with work after s Proceed with further work only after making proceed with further work. ATR not required. Inspection should be done after: after cleaning the apartment.	Project Manager Previous stage report no. Additions & alterations sheet date Checked By MD on Recommendation: Stop further work Company B-444 Rha -4 Rha Sridhew SHILISH Recommendation:
Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed only after recheck by QC. Proceed with further work only after making corrections pointed out in the QC report. ATR not required. Proceed with further work. ATR not required. after cleaning the apartment.	Quality Control Check Repot. Stage: After Plumbing & Electrical (Apartments) B-4/4 Other \$1. No. \$21. No. PMR - 1/4 Project PMR - 1/4 Phase 1 M-7/4 Sign A4 Date \$4.04 12 SHIRISH Sign A2 Date \$4.04 12 Sheet date \$8.02 12 All pages signed by engineer & customer? Yes \ No MD Sign MD Sign For filling Yes \ No

- before starting painting, tiling & flooring.
- electrical conduct, waterproofing & plumbing work is completed (for stage II only).
- additions & alterations sheets to be transferred to QC file. QC to check if A&A are made as per request. additions & alterations is finalized and signed. In case there are no additions and alterations printout of email by PM to CR confirming the same must be

After Plumbing & Electrical Check,

- Mark \checkmark for correct or minor mistake which does not require correction
- Mark X for minor mistake that requires minor correction.
- Mark imes imes for major mistake that requires correction by replacement or re-fixing.
- Mark XXX for major mistake that cannot be corrected.
- Location of CPVC & PVC fittings must be checked as per measurements given in circular. Tolerance 1".
- Water proofing must cover all pipes & check height above SFL. Civil work near pipes in balcony & utility must be neat and mortar should be removed from the pipes. Location, height and spirit level of electrical points must be checked as per measurements given in circular & plan. Tolerance 1".
- Fasteners must be used as specified in circular. Especially check fixing of PVC pipes.
- 11. In case of many changes in civil work, electrical work and plumbing work, a new drawing must be prepared at IIO and approved by MD. Height of DB box must be 6" below false ceiling level or 12" below slab level.

Quality Control Check Repot. Stage: After Plumbing & Electrical (Apartments)