## Quality Control Check Repot. Stage: After Plastering (Apartments)

Flat No. Company		Other Project	MES	Sl. No.  Phase	34886
Prepared by	M. Teja Smither	Sign	94	Date	05/1/18
Project Manager	Subba Reddy Sign	Sign	ren	Date	05/1/18
Previous stage report no.	no.	28011	Report filed and signed by PM?	ed by PM?	Nyes   No
Checked By MD on		MD Sign		For filling	Yes No
Recommendation:  Stop further work  Stop further work  Proceed with furt  Proceed with furt	Recommendation:  Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC.  Stop further work. Proceed with work after submitting ATR on QC report to QC team.  Proceed with further work only after making corrections pointed out in the QC report. ATR not required.  Proceed with further work. ATR not required.	eport to QC team. Proceer submitting ATR on cing corrections pointed ired.	eed only after recheck of QC report to QC team of out in the QC report.	by QC. ATR not required.	

## Inspection should be done after:

- brickwork & 2 coats plastering is completed
- after cleaning the apartment.
- water proofing, screeding in bathrooms is completed.
- before starting painting, tiling & flooring.

## Plastering Check.

- Mark ✓ for correct or minor mistake which does not require correction
- Mark X for minor mistake that requires minor correction.
- Mark XX for major mistake that requires correction by replacement or re-fixing. Mark XXX for major mistake that cannot be corrected.
- 9"unplastered area from SFL should be left including in common areas and terraces.
- Windows must be checked with templates. Plastering must be 3mm margin for luppum work. Tolerance 1/2".
- Provision of tiles in bathrooms, kitchen & wash areas (rough plastering). Check size of sink bowl. Hole should be 1" to 2" larger. (Tolerance: 1")
- Sill top must be of uniform thickness, correct height, at one level & without broken edges. All doors frames should have 1/2" grooves.