2	1		
1	1	1	
	1	-1	

Quality Control Check Repot. Stage: After Column Casting (villas)

Recommendation: Stop further work. Stop further work. Proceed with furth Proceed with furth	Checked By MD on	Previous stage report no.	Project Manager	Prepared by	Company	Block No.
Recommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR not required Proceed with further work. ATR not required.		no.	5		VOCCILP)	201
eport to QC team. Proce ter submitting ATR on sing corrections pointed ired.	MD Sign	31720	Sign	Sign	Project	Column No.
eed only after recheck QC report to QC team d out in the QC report.		Report filed and signed by PM?		ナススナ	Voc	02
by QC. 1. ATR not required.	For filling	ed by PM?	Date	Date	Phase	Sl. No.
	☐ Yes ☐ No	⊠Yes □No	31/10/18	31/10/19		81913

Columns Position Check. Notes:

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab.
- Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolcrance I")
- Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.
- .

Columns Position Check Plan enclosed?	. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention as
✓ Yes	imension with red colour and mention actual difficultion flexitio it.

Slab Dimensions Check.

Notes:

- 1. Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
- Show outer dimensions of slab. (Tolerance 2")
- Show length and width of balconies (Tolerance 1")
 Show inner dimensions of ducts and lift well. (Tolerance 1")
- Show location of sunken slab.
- Print an A3 size plan.
- colour. Circle each incorrect dimension with red colour and mention actual dimension next to it.

Slab Dimensions Check Plan enclosed? Virele each incorrect dimension with red colour and nicility. Slab Dimensions Check Plan enclosed? Virele each incorrect dimension with red colour and nicility. Virele each incorrect dimension with red colour and nicility.	Yes No	HIDERSHOIL HOAT TO IT.
Specified thickness of slab? 5^{nl}	Actual thickness of slab?	Z

Quality Control Check Repot. Stage: After Column Casting (villas)

Quality of centering, rod bending and concreting?] Good 💟 Avg. 🗌 Bad
Quality of starters?	☑Good ☐ Avg. ☐ Bad
Number and size of honey combs?]High Medium. Low
Are the honey combs is slab and columns packed?] Good 🗹 Avg. 🗌 Bad
Number of beams that are sagging, bulging, caved or deflected in the slab by more than 1"	, o
Have 6 cubes each for columns and slab casted and numbered for testing?	√Ycs □ No
Remarks:	
Curing.	
Bunds for curing made on slab?	
Bund size is less than 100 sft?	
Drum (200 lts) provided for curing?	
Gunny bags used for column curing?	
Distance of tap from furthest distance that requires curing. (max permitted 100') 50.0"	The state of the s
Frequency of curing in number of times a day (enquire from labourers)	
Is the pressure in the curing pipe more than 15' head?	
Quality of infrastructure for curing.	Bad
Remarks: Neil: one stais cose columns not costed.	

Quality Control Check Repot. Stage: After Column Casting (villas)

Columns height, plumb, steel & level marking check.

- Mark v for correct or minor mistake which does not require correction Mark x for minor mistake that requires minor correction.

 Mark x for major mistake that requires correction by replacement or re-fixing.

 Mark x x for major mistake that cannot be corrected.

Circle actual height of columns if level differs from specified height by more than 1". Tolerance: Plumb 0.25".

SNo

19 18 17. 16. 15 14 13. 12. 9 9 4. S 2 Col No. 4 42 W 4 70 194 S. C. 15 Col type 23 0 Ü S C 14-18 1 上多 ∞ 1,7 2,2 ±+1 8-4 24.8 Spec. 8-4-1 8-4 Height in ft 5-2" 8-2" 1,91117E 8,3 8-41/2 8-31 8,3: 5.7 8-410 Actual 874 8-1 No of rods Steel (✓ or 🗙) 4 rods Size of < < < 4 4 ۷. Honeycombs < < < Side 1 Plumb (✓ or 🗙) 4 < Side 2 < < ✓ Yes ✓ Yes ✓ Yes ✓ Yes ✓ Yes V Yes ✓ Yes V Yes Yes Yes Yes √ Yes Yes Yes Yes column? marked on Yes Reference level Yes Yes Yes Yes Yes Yes No LZo No No No LZO No LNo C No \square LNo □ No No [No No No Zo No