

Quality Control Check Repot. Stage: After Column Casting (villas)

Specified thickness of slab?	Notes: 1 Prepare Slab (or plinth beams) Dimensions a Show outer dimensions of slab of balcon b Show length and width of balcon c Show inner dimensions of duets a d. Show location of sunken slab e Print an A3 size plan. 2 Circle each correct dimension with green c Slab Dimensions Check Plan enclosed?	Slab Dimensions Check	3 Circle each correct dim	Inspection should be done afte Prepare Columns Position Che a Dicide blocks into sm b Show size and oriente c. Show inner inner sp d. Show diagonals for 2 e. Print an A3 size plan.	Columns Position Check Notes:	Recommendation: Stop further work. Stop further work. Proceed with further	Checked By MD on	Previous stage report no.	Project Manager	Prepared by	Company	Block No. 240
dab?	Prepare Slab (or plinth beams) Dimensions ('heck Plan as follows a Show outer dimensions of slab, cloter ince 2") b Show length and width of balcomes (Loierance 1") c Show inner dimensions of duets and lift well (Tolerance 1") d. Show location of sunken slab e Print an A3 size plan. Circle each correct dimension with green colour. Circle each incorrect b Dimensions Check Plan enclosed?	K Flan chelosed	ension with green colour	Inspection should be done after casting of columns at each stage and Prepare Columns Position Check Plan as follows: a Disade blocks into smaller sub-blocks b Show size and orientation of columns. (Tolerance 0.5") c. Show inner inner space between columns. (Tolerance 1") d. Show diagonals for 20% of bays. (Tolerance 1.5") c. Print an A3 size plan.	<u> </u>	Stop further work. Submit ATR on QC report Stop further work. Proceed with work after su Proceed with further work only after making a Proceed with further work. ATR not required.		,o	Asuresh	S. kuldeep	VOC((LP)	(Constant
07 =	c Plan as follows ce 2") erance 1") well (Tolerance 1")		Circle each incorrect dime	is at each stage and before following (1.5") ins. (Tolerance 1.5") ince 1.5")		port to QC team. Prooter submitting ATR or ing corrections pointeined.	MD Sign	31072	Sign	Sign	Project	Column No.
Actual thickness of slab?	Prepare Slab (or plinth beams) Dimensions ('heck Plan as follows a Show outer dimensions of slab, cloter ince 2") b Show length and width of balcomes (Loierance 1") c Show inner dimensions of duets and lift well (Tolerance 1") d. Show location of sunken slab e Print an A3 size plan. Circle each correct dimension with green colour. Circle each incorrect dimension, with red colour, and mention b Dimensions Check Plan enclosed?		red co	Inspection should be done after casting of columns at each stage and before starting centering works for each Prepare Columns Position Check Plan as follows: a Divide blocks into smaller sub-blocks b Show size and orientation of columns. (Tolerance 0.5") c. Show inner inner space between columns. (Tolerance 1") d. Show diagonals for 20% of bays. (Tolerance 1.5") c. Print an A3 size plan.		Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QU Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR Proceed with further work. ATR not required.		Report filed and signed by	S		NOC	07
ab?	ennon actual dimension next to it		ention actual dimension next to it	77		by QC. ATR not required.	For filling	ed by PM?	Date	Date	Phase	SI. No.
	kt to it		At to it				☐ Yes ☐ No	Yes No	8192/60/10	04/09/2010	١	31271

Quality Control Check Repot. Stage: After Column Casting (villas)

Quality of centering, rod bending and concreting.		
Quality of centering, rod bending and concreting?		Good Avg. Bad
Quality of starters?		Good Avg. Bad
Number and size of honey combs?		☐ High Medium. ☐ Low
Are the honey combs is slab and columns packed?		☐ Good Avg. ☐ Bad
Number of beams that are sagging, bulging, caved or deflected in the slab by more than I"	ıan I"	\
Have 6 cubes each for columns and slab casted and numbered for testing?		☐Ycs ☐ No
Remarks:		
Bunds for curing made on slab?	Yes No	
Bund size is less than 100 sft?	Xes No	
Drum (200 lts) provided for curing?	Yes No	
Gunny bags used for column curing?	ZYes □No	
Distance of tap from furthest distance that requires curing. (max permitted 100')	301-0"	- Andrews
Frequency of curing in number of times a day (enquire from labourers)	2 times	
Is the pressure in the curing pipe more than 15' head?	Yes No	
Quality of infrastructure for curing.	☐Good ☐ Avg. [Bad
Remarks:		

Columns height, plumb, steel & level marking check. Notes:

- Mark > for correct or minor mistake which does not require correction
 Mark X for minor mistake that requires minor correction.
 Mark X for major mistake that requires correction by replacement or re-fixing.
 Mark X X for major mistake that cannot be corrected.
 Tolerance: Plumb 0.25".

6
Circl
e actu
al heig
ht of a
olum
ns if h
vel d
iffers 1
rom s
6. Circle actual height of columns if level differs from specified height by more than 1.".
height
by mo
re thar
1-

= = = = = = = = = = = = = = = = = = =	<u>-</u>	<u></u>	<u> </u>] (1		7.	<u></u>		12		10.	9	×	7	6.	ĺγ	4.	ب	1)				SNo
						:			CTI W	<u>-</u>	DQ.	Ç,	c_1	20	B	8,	Au	Аз	A ₂	P			Col No.
									53	Ch	2	63	Cy	43	C3	77	C 1	Cr	61	C)			o Col No. Col type Height in ft Steel (or x)
			ļ			†	İ		8.7"	8.7	8.7	81. 3/2."	Stair	8! 3"	8.31	Stain	4.0	81. 71/2"	81. 412"	8175"	7	Spec.	Height in ft
									8:2"	81.1"	11.8	8171511	8 600	2.4=	3	staire	81-6"	81.70	81.71	81-7"		Actual	t in ft
	+	-		İ		-+			(7	(_	<	1	7	7	(•	<	(rods	No of	Steel (v or x)
									<	7	<	1	<	\	ς	(<	<	<	7	rods	Size of	or ×)
									(1	1	7	7	7	7	, ,	7	7	7	5			Honeycombs
									<	((<	<	7	<	5	1	7	5	5		Side 1	1 8
		+ :	† !	•	:		!	1	1	, ,	; ((, <	7	<	-		K 	<	<	_		Side 2	Plumb (v or x)
Yes		Yes No	Yes UNO] [TVec TNo	☐ Yes ☐ No	Yes No	ŀΓ	٦İ				$\neg \Gamma$			Vec No						column'	Reference level