·~
<i>uality</i>
' Control
Check Repot.
Stage: After Column Casting (vi
Casting (
(villas)

Recommendation: Stop further work. Stop further work. Proceed with furth Proceed with furth	Checked By MD on	Previous stage report no.	Project Manager	Prepared by	Company	Block No.
Recommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR not Proceed with further work. ATR not required.		no.	totes works	Sishil Kump	MRM(12P)	39
eport to QC team. Proc fler submitting ATR on cing corrections pointed ired.	MD Sign	29157	Sign	Sign	Project	Column No.
eed only after recheck l QC report to QC team d out in the QC report.		Report filed and signed by	K deepeer Xas Date	1	AVR GLIMOTUS	03
by QC. ATR not required.	For filling	d by PM?	Date	Date	Phase	SI. No.
	☐ Yes ☐ No	LYes □No	06/02/18	06/02/18)	29861

Columns Position Check, Notes:

- Inspection should be done after easting of columns at each stage and before starting centering works for each slab.
- 2. Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1")
- Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.

- 99		
<u>.</u>	Ω	s.
7	lum	Circ
•	ns Po	ile ea
	ositic	ch cor
2	n Cl	rect c
4	ıeck	limen
	eck Plan e	a uois
	encl	71th gi
	Columns Position Check Plan enclosed?	Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention a
		olour,
		Circl
		e eac
		n inco
		rrect
		dimen
	Д	Sion V
	Yes □No	vith re
		ed col
	No	our ar
		id me
	,	ntion
		actual
		dimens
		nsion
		sion next to it
		0 It.
L		

Slab Dimensions Check.

Notes:

- 1. Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
- Show outer dimensions of slab. (Tolerance 2")
- Show length and width of balconies (Tolerance 1")
 Show inner dimensions of ducts and lift well. (Tolerance 1")
- Show location of sunken slab.
- Print an A3 size plan.
- Sla Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it.

Slab Dimensions Check Plan enclosed?	S
Specified thickness of slab? Actual thickness of slab? And the slab is the s	5? A'k

Quality Control Check Repot. Stage: After Column Casting (villas)

Quality of centering, rod bending and concreting?	☐ Good ☐ Avg. ☐ Bad
Quality of starters?	Good Avg. Bad
Number and size of honey combs?	☐ High ☐ Medium. ☐ Low
Are the honey combs is slab and columns packed?	☐ Good ☐ Avg. ☐ Bad
Number of beams that are sagging, bulging, caved or deflected in the slab by more than 1"	than I"
Have 6 cubes each for columns and slab easted and numbered for testing?	☐Yes ☐ No
Remarks:	
Curing.	
Bunds for curing made on slab?	Yes No
Bund size is less than 100 sft?	Yes No
Drum (200 lts) provided for curing?	Ycs No
Gunny bags used for column curing?	∠Yes □No
Distance of tap from furthest distance that requires curing. (max permitted 100')	40-0
Frequency of curing in number of times a day (enquire from labourers)	2 films
Is the pressure in the curing pipe more than 15' head?	□Yes □No
Quality of infrastructure for curing.	☐ Good ☑ Avg. ☐ Bad
Remarks:	

Columns height, plumb, steel & level marking check. Notes:

- Mark v for correct or minor mistake which does not require correction
 Mark X for minor mistake that requires minor correction.
 Mark X for major mistake that requires correction by replacement or re-fixing.
 Mark X for major mistake that cannot be corrected.
 Tolerance: Plumb 0.25".
 Circle actual height of columns if level differs from specified height by more than 1".

	- 1	
	- 4	
ζ ,	1	(
ς ς	,	,
′	1	(
	`	(
rods rods		Side 1
	3	