 Quality
Control
Quality Control Check Repot. St
age
\cdot Colum
Ξ
in Casting

Columns Position Check.

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab.
- Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1")
- Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.

3. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention ac	nsion with red colour and mention actual dimension next to it.
Columns Position Check Plan enclosed?	☐Yes ☐ No

Slab Dimensions Check.

- Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
- Show outer dimensions of slab. (Tolerance 2")
- Show length and width of balconics (Tolerance 1") Show inner dimensions of ducts and lift well. (Tolerance 1")
- Show location of sunken slab.
- Print an A3 size plan.
- Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it.

Specified thickness of slab?	Slab Dimensions Check Plan enclosed?	2. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention a
Actual thickness of slab?	∑Yes □No □	ension with red colour and mention actual dimension next to it.

Quality Control Check Repot. Stage: After Column Casting (villas)

Quality of centering, rod bending and concreting.	
Quality of centering, rod bending and concreting?	Good Avg. Bad
Quality of starters?	☐ Good ☐ Avg. ☐ Bad
Number and size of honey combs?	☐ High ☐ Medium. ☑ Low
Are the honey combs is slab and columns packed?	☐ Good ☐ Avg. ☐ Bad
Number of beams that are sagging, bulging, caved or deflected in the slab by more than 1"	-
Have 6 cubes each for columns and slab casted and numbered for testing?	☑ Yes ☐ No
Remarks:	
Curing.	
Bunds for curing made on slab?	No
Bund size is less than 100 sft?	No .
Drum (200 lts) provided for curing?	No
Gunny bags used for column curing?	No
Distance of tap from furthest distance that requires curing. (max permitted 100') 50'-0"	
Frequency of curing in number of times a day (enquire from labourers)	
Is the pressure in the curing pipe more than 15' head?	117
Quality of infrastructure for curing.	INO
Remarks:	Avg. Bad

Columns height, plumb, steel & level marking check.

- Mark \vee for correct or minor mistake which does not require correction Mark \times for minor mistake that requires minor correction.

 Mark \times for major mistake that requires correction by replacement or re-fixing. Mark \times for major mistake that cannot be corrected.
- Tolerance: Plumb 0.25".

Circle actual height of columns if level differs from specified height by more than 1".

20.	19.	18.	17.	16.	15.	14.	13.	12.	11.	10.	9.	.8	7.	. 6.	5.	4.	3.	2.	<u>.</u>		SNo
-	ļ.,	·~	.7). 		1.2	.3	2.	1.	0.							•				
															•	82	251	A)	A ₁		Col No.
																Cr	C1	Cy	C3		Col type
							and the state of t									81-4"	81-74	81-71	81-711	Spec.	Heig
																Q -411	ς'-4"	19-19 19-19	81-611	Actual	Height in ft
																V	ζ.	ς.	ς.	No of rods	Steel
			22													<	,	7	7	Size of rods	Steel (v or x)
																<	<	۲	ς .		Honeycombs
																<	<	ς.	<	Side 1	Plumb
	33								di Managanana -							7	<	7	7	Side 2	Plumb (v or x)
☐ Yes ☐ No	☐Yes ☐No	□Yes □No	☐Yes ☐No	☐Yes ☐No	□Yes □No	☐ Yes ☐ No	☐Yes ☐No	□Yes □No	□Yes □No	□Yes □No	∐-Yes □No	☑Yes □No	Yes □No		marked on column?	Reference level					