

Quality Control Check Repot. Stage: After Column Casting (villas)

1	7				
Block No.	94	Column No.	0	SI. No.	50903
Company	SOV (LLP)	Project	Sov	Phase	\bar{x})
Prepared by	S. Kuldeet	Sign	Sander L	Date	21/07/2018
Project Manager	K. Pusshotterm	Sign	P	Date	21/07/2018
Previous stage report no.	no.	20689	Report filed and signed by PM?	d by PM?	Yes No
Checked By MD on		MD Sign		For filling	☐ Yes ☐ No
Recommendation: Stop further work. Stop further work. Proceed with furth	Recommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR not required.	port to QC team. Proce ter submitting ATR on ing corrections pointed ired.	ed only after recheck be QC report to QC team. I out in the QC report.	y QC. ATR not required.	
Columns Position Check	-Ck				

Notes:

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab. Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1")
- Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.

Columns Position Check Plan enclosed?	S. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actu
XYCS No	ecorrect dimension with red colour and mention actual dimension next to it.

Notes: Notes:

- Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
- Show outer dimensions of slab. (Tolerance 2")
 Show length and width of balconies (Tolerance 1")
 Show inner dimensions of ducts and lift well. (Tolerance 1")
- Show location of sunken slab.
- Print an A3 size plan.

Slab Dimensions Check Plan enclosed?	blour. Circle each incorrect dim	ension with red colour and mention actual di Yes No Actual thickness of slab?	imension next to it.
	Specified thickness of slab?	Actual thickness of slab?	The same of the sa

Quality Control Check Repot. Stage: After Column Casting (villas)

Chand Aver Bad
Dave. Dau
Good Avg. Bad
High Medium. Low
Good Avg. Bad
and the state of t
No

Columns height, plumb, steel & level marking check. Notes:

Mark ✓ for correct or minor mistake which does not require correction
 Mark X for minor mistake that requires minor correction.
 Mark XX for major mistake that requires correction by replacement or re-fixing.
 Mark XX for major mistake that cannot be corrected.
 Tolerance: Plumb 0.25".
 Circle actual height of columns if level differs from specified height by more than 1".

																						2
20.	19.	18.	17.	16.	15.	14.	13.	12.	11.	10.	9.	œ.	7.	6.	5.	4.	3.	2.	1.			S No
						F3	F2	F ₁	さと	€ı	\mathcal{P}_3	Q1	ç	c1	83	82	в,	Az	A			Col No.
						0,	C,	<i>C</i>)	C2_	2	C2	7.0	C2	c7	C3	Cz	<i>c</i>)	Cy	C3			Col type
						14:8	8.4"	8.4"	8,7,8	8.7"	8. H.	8,4	8,41	81.44	ءُ _مم	8.70	Stain	8.7"	Stairs	Yeste	Spec.	Heigh
			7.000 (7.000)			8:65"	2,4	8'.61/2"	8:35"	8.6.	8.35"	8.6"	82.3	8'.61,1	8.u/s"	8.61	stain	8 . 4 . 4 .	stair		Actual	Height in ft
						ς.	ς	ζ	<	2	<	<	<	<	ς .	ζ	7	ζ	7	rods	No of	Steel (
						7	<	<	<	Ċ,	7	2	<	7	1	5	ς	ί	ζ	rods	Size of	Steel (vor x)
Contraction (a)						<	7	<	<	ς .	7	(7	(7	(7	7	7			Honeycombs
						(((<	<	(\	7	(9	1	<	1	(Side 1	Plumb
						<	<	<	(<	2	(<	<	\	(<	1	1		Side 2	Plumb (or ×)
☐Yes ☐No	☐Yes ☐No	∐Yes ∐No		$\ -$				ı		ĺГ	∐Yes □No		le	-			 			``	marked on	Reference level