	Quality Contr	Quality Control Check Repot.	Stage: After Column Casting	Casting (villas)	ST.
Block No.	93	Column No.	0)	SI. No.	30483
Company	SOV (LLP)	Project	201	Phase	X
Prepared by	Sikulderp	Sign	Chyder	Date	20 07 2018
Project Manager	Purshothom. K	Sign	X	Date	20/07/2018
Previous stage report no.	no.	30657	Report filed and signed by PM?	ed by PM?	Yes No
Checked By MD on		MD Sign		For filling	☐ Yes ☐ No
Recommendation: Stop further work. Stop further work	Recommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team.	eport to QC team. Pro	scommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team.	by QC.	

Columns Position Check.

Proceed with further work. ATR not required.

Proceed with further work only after making corrections pointed out in the QC report. ATR not required

Notes:

- Inspection should be done after easting of columns at each sage and before starting centering works for each slab
- Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Ġ, Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1")
- Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.
- Ω^{ω} .

Check Plan enclosed?	s. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention act
☐Yes ☐ No	sion with red colour and mention actual dimension next to it.

Slab Dimensions Check.

o. c - c - a Show outer dimensions of slab. (Tolerance 2")

Prepare Slab (or plinth beams) Dimensions Check Plan as follows:

- Show inner dimensions of ducts and lift well. (Tolerance 1") Show length and width of balconies (Tolerance 1")
- Show location of sunken slab.
- Print an A3 size plan.
- Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it

The same and the same of the s	Specified thickness of slab?	Slab Dimensions Check Plan enclosed?	2. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention a
	Actual thickness of slab?	ØYes □No	sion with red colour and mention actual d
	***************************************		imension next to it.

Quality Control Check Repot. Stage: After Column Casting (villas)

Quality Control Check Repot. Stage: After Column Casting (villas)

Columns height, plumb, steel & level marking check.

- Mark v for correct or minor mistake which does not require correction
 Mark X for minor mistake that requires minor correction.
 Mark XX for major mistake that requires correction by replacement or re-fixing.
 Mark XX for major mistake that cannot be corrected.
 Tolerance: Plumb 0.25".
 Circle actual height of columns if lavel discense.

S No	o Col No. Col type Height in ft Steel (or x)	Col type	Heig	Height in ft	Steel	Steel (v or x)	Honeycombs	Plumb	Plumb (v or x)	Reference level
			Spec.	Actual	No of	Size of		Side 1	Side 2	marked on
					rods	rods				column?
-	<i>A</i> 1	63	8.41	8.3"	1	ζ	(\	☑Yes □No
2.	A.	2	814"	8'.3'5"	7	,	ζ.	ς .	(☑Yes □No
į.	B	C1	8.4"	8'.3"	(ς	<	7	7	☐Yes ☐No
4.	573	ĈL.	∞_ 	ر ا ا	7	((7	7	∏'Yes □No
5.	Bs	C3	8.44	B . 8°	ς.	7	(((☐Yes ☐ No
0.	0	()	B. 4"	13/21	(ς	(7	(∑Yes □ No
) ·	3	62	<u>م</u>	B. 4.	<	_	(7	(Yes No
o o	D ₁	C	P. H.	8-31,"	5	(<	7	(∠Yes \\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\
9.	27	47	8.u"	81.31	ς	7	(((✓Yes □No
10.	0	C)	8.41	61.31/2"	ς	((((√Yes □ No
	EL	7)	8,41	81.3"	<	(7	ζ	(☑Yes □No
12.	F.	Ci	8.4"	8.3/20	5	((((☑Yes □No
13.	37	62	" " 2	8'. 3'8"	۲	1	(1	1	☑Yes □No
14.	ا ا	Ĉ)	G	81.31	(7	\	7	(√ Yes □ No
15.										☐Yes ☐No
16.										☐Yes ☐No
17.								-		☐ Yes ☐ No
18.										☐Yes ☐No
19.										☐ Yes ☐ No
20.		_								Vec No