Ouality Control
v Control Check Repot.
Stage: After Column Casting (villas)

Recommendation: Stop further work. Submit ATR on QC report Stop further work. Proceed with work after stop further work. Proceed with further work only after making of Proceed with further work. ATR not required	Checked By MD on	Previous stage report no.	Project Manager	Prepared by	Company	Block No.
Submit ATR on QC re Proceed with work af er work only after mak er work. ATR not requ		10.	Nachtu Sudhan Sign	S. Kuldeep	wildie Estat	= 6
eport to QC team. Proc fter submitting ATR or king corrections pointe nired.	MD Sign	30665	Sign	Sign	Project	Column No.
ecommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR not required.		Report filed and signed by PM?	Mi what Date	Simoley-	wilding Estate	03
by QC. ATR not required.	For filling	ed by PM?	Date	Date	Phase	Sl. No.
	Yes No	Yes No	8/07/2018	8105/2018	=7	30853

Columns Position Check. Notes:

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab.
 Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1")
- Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.
- xt to it

	w
Columns Position Check Plan enclosed?	3. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention accounts and mention accounts and mention accounts and the colour accounts and the colour and mention accounts and the colour and the colour accounts account accounts and the colour accounts account accounts and the colour accounts account accounts and the colour accounts accounts account accounts and the colour accounts acc
Yes UNo	nension with red colour and mention actual difficultivities to it.

Slab Dimensions Check. Notes:

- Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
 a. Show outer dimensions of slab. (Tolerance 2")
- Show length and width of balconies (Tolerance 1")
 Show inner dimensions of ducts and lift well. (Tolerance 1")
- Show location of sunken slab.
- Print an A3 size plan.

2 Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention ac	rreen colour. Circle each incorrect dimens	sion with red colour and mention actual d	limension next to it.
2. CHOIC CACH COILECT CHIMENSON WITH	210071 4010111 011010 0001		
Slab Dimensions Check Plan enclosed?		Yes No	
Specified thickness of slab?	<u></u>	Actual thickness of slab?	2
	•		

Quality Control Check Repot. Stage: After Column Casting (villas)

Quality of centering, rod bending and concreting?		☐ Good ☑ Avg. ☐ Bad
Quality of starters?		☐ Good ☑ Avg. ☐ Bad
Number and size of honey combs?		☐ High ☐ Medium. ☐ Lov
Are the honey combs is slab and columns packed?		☐ Good ☐ Avg. ☐ Bad
Number of beams that are sagging, bulging, caved or deflected in the slab by more than 1'	than I"	and the second s
Have 6 cubes each for columns and slab casted and numbered for testing?		□Yes □ No
Remarks:		
Curing		
Bunds for curing made on slab?	☑Yes □No	
Bund size is less than 100 sft?	Yes No	
Drum (200 lts) provided for curing?	☐Yes ☑No	
Gunny bugs used for column curing?	∠ Yes ☐ No	
Distance of tap from furthest distance that requires curing. (max permitted 100')	30 ¹ ,0 ¹⁾	
Frequency of curing in number of times a day (enquire from labourers)	2-times	
Is the pressure in the curing pipe more than 15' head?	∐Yes □No	
Quality of infrastructure for curing.	Good Avg.	Bad
Remarks:		

Columns height, plumb, steel & level marking check.

Notes:

- Mark v for correct or minor mistake which does not require correction

 Mark X for minor mistake that requires minor correction.

 Mark XX for major mistake that requires correction by replacement or re-fixing.

 Mark XX for major mistake that cannot be corrected.

 Tolerance: Plumb 0.25°.

Circle actual height of columns if level differs from specified height by more than 1".

				1	3	1					γ —						_					2
20.	19.	18.	17.	16.	15.	14.	13.	12.	11.	10.	9.	,8	7.	6.	5.	4.	ب.	2.	1.			SNo
																3	D.#	40	88			Col No.
													The state of the s			C,	C2	Cz	()			Col type
									10000							01.47	8:4"	4:18	4		Spec.	Heig
														000000000000000000000000000000000000000		81.71%	81.46"	e1.612"	8.62		Actual	Height in ft
						Acceptance of the Control of the Con										<	7	7	<	rods	No of	Steel (
												00-00				~	((ſ	rods	Size of	Steel (✓ or X)
																ζ	?	۲	(Honeycombs
																<	1	ς	/		Side 1	Plumb
							e e e e e e e e e e e e e e e e e e e									5	\	\	/	•	Side 2	Plumb (or x)
☐ Yes ☐ No	☐Yes ☐No	☐Yes ☐No	☐ Yes ☐ No	□Yes □No	☐Yes ☐No	□Yes □No	☐Yes ☐No	□Yes □No	□Yes □No	□Yes □No	☐Yes ☐No	□Yes □No	☐Yes ☐No	☐Yes ☐No	☐Yes ☐No	Yes No	Yes No	∐Yes □No	☐Yes ☐No	column?	marked on	Reference level
																				5000		