Quality Control Check Repot. Stage: After Column Casting (villas)

77					
Block No.	125	Column No.	<u> </u>	SI. No	72542
Company	100 (TTb)	Project	Vac	Phase	
Prepared by	V. Sanketh	Sign	4. 5. 7. 4.	Date	5 5
Project Manager		Sign		Date	21 C. F. T.
Previous stage report no.	no.	31623	Report filed and signed by	d by PM?	Yes No
Checked By MD on		MD Sign		For filling	□Ycs □No
Recommendation: Stop further work. Stop further work. Proceed with furth Proceed with furth	Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck l Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. Proceed with further work. ATR not required.	port to QC team. Procer submitting ATR on ing corrections pointed ired.	Recommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR not required.	y QC. TR not required.	
Columns Position Check.	ck.	1.			

Notes:

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab. Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1")
- Show diagonals for 20% of bays, (Tolerance 1.5")
- Print an A3 size plan.

h Dimensions Check	olumns Position Check Plan enclosed?	Circle each correct dimension with green colour. Circle each incor-
	Yes No	mension with red colour and me

Notes:

- 1. Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
- Show outer dimensions of slab. (Tolerance 2")
 Show length and width of balconies (Tolerance 1")
 Show inner dimensions of ducts and lift well. (Tolerance 1")
- Show location of sunken slab.
- Print an A3 size plan.
- 2. Cir. Slab D Circle each correct dimension with green colour. Circle each ir

xt to it.

Quality Control Check Repot. Stage: After Column Casting (villas)

Quality Control Check Repot. Stage: After Column Casting (villas)

Columns height, plumb, steel & level marking check. Notes:

- Mark v for correct or minor mistake which does not require correction
 Mark X for minor mistake that requires minor correction.
 Mark XX for major mistake that requires correction by replacement or re-fixing.
 Mark XX for major mistake that cannot be corrected.
 Tolerance: Plumb 0.25°.

Circle actual height of columns if level differs from specified height by more than 1".

	20.	19.	18.	17.	5 5	16.	15	14	13	12.	1.	10.	9.	, ×		0.	, i	4.	υ.	2.	.		SNo
											ק י	ō	Cq	CI	2	134	2	81	AL	£ (A.		Col No.
											ડર	B	3	K	C3	C3	C4		2	C3	(1		Col type
											8-1	81.47	8-11	Q`_"	steises	8-4"	8-1"	Stains	814"	11/2/18	16.0	Spec.	Heigl
											0 <u>.</u>	0 - 0 -	8,9	8-3	Stores	8-3"	8-0"	Stairs	8-6"	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	815 "	Actual	Height in ft
											<	Ć.	<	<	\	<	<		<	<	4	No of rods	Steel (
											<	۷.	<	<	<	<	<	ς ,		7	~	Size of rods	Steel (or x)
												<	<	<	(<	<	7		,	<		Honeycombs
										1	<	<	ς	<	<,	./	<	ζ,			<	Side 1	Plumb
										,	\ \	<	<	<	C C	(<u> </u>		- (`	Side 2	Plumb (or ×)
[100 100	$\exists f$	□Yes □No	☐Yes ☐ No	☐ Yes ☐ No	☐ Yes ☐ No	∐Yes ∐No	1 _	1 –	7	Yes No	✓ Yes □ No	✓ Yes □ No	Ycs No	☐ Yes ☐ No	Yes No	∠ Yes No	Yes No	√Yes □No	Yes No	✓ Yes □ No	✓ Yes ☐ No	marked on column?	Reference level