Quality Contro
ty Control Check Repot.
Stage: After Column Castin
nn Casting (villas)

	Company Prepared by Project Manager Previous stage report	voc (LLP) S. Kulstep A. Surush	Column No. Project Sign Sign	VC Phase Phase Phase Date Report filed and signed by PM?	SI. No Phase Date Date Date
Sign 29677 MD Sign	ared by	Sikuldup	Sign	Duder	1
1 no. 29677 MD Sign	roject Manager	A-Swush	Sign	(\	
	revious stage report	rt no.	29677	Report filed a	nd signe
	Checked By MD on		MD Sign		
K - The state of t	Column Position Check	H-1, N			

2

In the problem should be done affected tuge of columns at each stage and before starting centering works for each slab. Propose defining the about heat Plan as follows:

Problebb Estato mallo sub blocks

'drow size and outcutation of columns, (Tolerance 0.5")

Show timer apace between columns. (Tolerance 1")

Show diagonals for 20% of bays. (Tolerance 1.5**)

Print an A3 size plan.

Columns Position Check Plan enclosed? 3 Uncle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it. Yes No

Slab Dimensions Check.

Notes:

1. Prepare Slab (or plinth beams) Dimensions Check Plan as follows:

Show outer dimensions of slab. (Tolerance 2")

Show length and width of balconies (Tolcrance 1")

Show inner dimensions of ducts and lift well. (Tolerance 1")

Show location of sunken slab.

Print an A3 size plan.

Specified thickness of slab? Slab Dimensions Check Plan enclosed? Circle cach correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it. ab Dimensions Check Plan enclosed?

| Yes | No Actual thickness of slab?

1

Quality Control Check Repot. Stage: After Column Casting (villas)

Columns height, plumb, steel & level marking check.

- Mark X for minor mistake that requires minor correction.
 Mark XX for major mistake that requires correction by replacement or re-fixing.
 Mark XX for major mistake that cannot be corrected.
 Tolerance: Plumb 0.25".
 Circle actual height of columns if level differs from specified height by more than 1". Mark

 for correct or minor mistake which does not require correction
 Mark

 for minor mistake that requires minor correction.
 Mark

 for major mistake that requires correction by replacement or re-fixing.
 Mark

 K

 for major mistake that cannot be corrected.
 Tolerance: Plumb 0.25".

20.	19.	18.	17.	16.	15.	14.	13.	12.	11.	10.	9.	×.		<u>,</u>	اد ا	,	دد:	iɔ	1.			SNo
					-				S.	Þ	ch	C3		73	13	B	Ðų	Ð	₽			Col No.
								J	3	Ć2	33	S	4	C.3	6.5	C J	7	(3	2			Col type
									6	8,4,8	ය <u>ි</u>	8. 1.	Staire	8! /"	11 1 8	Stair	# F :8	1, t. is	@		Spec.	Heig
									8:115"	ω 	_= &=	81.150	Staire	8	4.18	Spirit.	69. 4. 1	181.67.18	14,8		Actual	Height in ft
									<	ζ	<	٤	C	\	5	<	7	?	7	rods	No of	Steel (
									_	ر	<	<	<	<	2	ζ.	(<	ζ	rods	Size of	Steel (or x)
									<	ς.	<u></u>	Ç	<u></u>	K	ς.	7	7		ς		. 1	Honeycombs
									ر	<	<	<	<	ς.	ζ	<	7	C	2		Side 1	Plumb
			-						<	ς.	<	2	<	2	(<	7	<	<		Side 2	Plumb (v or x)
☐ Yes ☐ No	□Yes □No	☐Yes ☐No	Yes No	✓ Yes □ No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No		Yes No	☑Yes ☐No	Yes No	column?	marked on	Reference level					