Quality Control Check Repot. Stage: After Column Casting (y	
	ua
	litγ
	Ö
	2
	$\overline{\Box}$
	he
	F
	\mathcal{R}_{e}
	00
Stage: After Column	•
Stage: After Column	
age: After Colum	S
e: After Column	20
After Column	e: .
er Columi	
Column	Cr.
ılumı	S
Imi	H
	Im
	as
as	Ė
astin	2
asting (v	~

Checked By MD on MD Sign For filling
t no. 30758 Report filed and signed MD Sign
MD Sign

Columns Position Check.

Notes:

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab.
- Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1")
- Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.
- 1

n enclosed?	ach coffeet dimension with gleen coletti. Chele ach incorrect dimension
es No	VIEW COROLL AND HIGHLIGH ACTUAL ALTERNATION (ICAC TO IT.

Slab Dimensions Check.

Notes:

- 1. Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
- Show outer dimensions of slab. (Tolerance 2")
- Show length and width of balconies (Tolerance 1")

Show inner dimensions of ducts and lift well. (Tolerance 1")

- Show location of sunken slab.
- Print an A3 size plan.

Specified thickness of slab?	Slab Dimensions Check Plan enclosed?	2. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and men
Actual thickness of slab?	□ Yes □ No =	ension with red colour and mention actual di
◆ -372 a		ition actual dimension next to it.

Quality Control Check Repot. Stage: After Column Casting (villas)

Quality Control Check Repot. Stage: After Column Casting (villas)

Columns height, plumb, steel & level marking check.

- Mark v for correct or minor mistake which does not require correction
 Mark x for minor mistake that requires minor correction.
 Mark x for major mistake that requires correction by replacement or re-fixing.
 Mark x x for major mistake that cannot be corrected.
 Tolerance: Plumb 0.25".
 Circle actual height of columns if level differs from specified height by more than 1".

Yes No										20.
☐ Yes ☐ No								į	i	19.
Yes No										18.
Ycs No										17.
Ycs No										16.
☐ Yes ☐ No				_						15.
☐ Yes ☐ No										14.
☐ Yes ☐ No			3							13.
∐Yes ∐No							17 Julius 190	\		12.
ľП	<	<	<	<	<	8-25"	8-1	5	D-	1.
	_	<	<	<	_	8-51	4.	Ç	D_	10.
	\		(<	4	8-1=		çν	2	9.
Yes No	<	<	\	_	<	8'-2"	1-18	ا م	(1-	œ
	<	<u>_</u>	<	~	<	5 ams	stains	Ç	()	7.
	_	<	<	<u> </u>	<	8-2"	8-1"	Ç-	13/	6.
	1	~	<	1	<	114-18	14-18	7	73	5.
	<	<	<	<	<	Sheins	Clairs	2	ᅺ	4.
Yes No	1	<	<	<	<	8-6-11		<u>در</u>	Ð	3.
Yes No	<	~	<	<	ζ,	8-811	_	S -	₽.	2.
Yes No	X	<	<	<u>ر</u>	~	S-71	14-18	C	A,	I.
column:				rods	rods		NACO			
marked on	Side 2	Side 1		Size of	No of	Actual	Spec.			
Reference level	Plumb (• or ×)	Plumb	Honeycombs	Steel (or x)	Steel (Height in ft	Heigh	Col type	Col No.	S No
7		11.				,				