## Quality Control Check Repot. Stage: After Column Casting (villas)

Recommendation:  Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report.  Proceed with further work. ATR not required.	Checked By MD on	Previous stage report no.	Project Manager		Company	Block No.
ibmit ATR on QC re- roceed with work aft work only after maki			A. Swest	V. Sarrheth	LCC (TTD)	34
port to QC team. Proce er submitting ATR on ing corrections pointed ired.	MD Sign	30819	Sign	Sign	Project	Column No.
		Report filed and signed by PM?	Ç	J. Sombert	Jol	02
tby QC. n. ATR not required.	For filling	d by PM?	Date	Date	Phase	SI. No.
	☐ Yes ☐ No	ŊŶes □No	81/4/87	0   H   & C		30984

### Columns Position Check,

Notes:

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab. Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1")
- Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.

\\ \frac{2}{\sqrt{2}}\right	Co	3
lah Dimensions Check	Columns Position Check Plan enclosed?	. Circle each correct dimension with green
	d? \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	2. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it

- Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
- Show outer dimensions of slab. (Tolerance 2")
- Show length and width of balconies (Tolerance 1")
- Show location of sunken slab. Show inner dimensions of ducts and lift well. (Tolerance 1")
- Print an A3 size plan.
- S 2 Circle each correct dimension with green colour. Circle each inco

Specified thickness of slab?	Slab Dimensions Check Plan enclosed?						
(5)	?	GILL D					
Actual thickness of slab?	∠Yes □No	ision with red colour and mention actual					
M <sub>L</sub>		dimension next to it.					

# Quality Control Check Repot. Stage: After Column Casting (villas)

Good WAvg. Bad
Good NAvg. Bad
]High ☐ Medium. ☑ Lov
Good Avg. Bad
~Yes □ No
Bad

## Columns height, plumb, steel & level marking check. Notes:

- Mark v for correct or minor mistake which does not require correction
   Mark X for minor mistake that requires minor correction.
   Mark X for major mistake that requires correction by replacement or re-fixing.
   Mark X X for major mistake that cannot be corrected.
   Tolerance: Plumb 0.25".

かどう Circle actual height of columns if level differs from specified height by more than 1".

Vo Col No Col type Height in ft Steel (1.27.2)

								ļ -					1					_			7		V.
20.	19.	18.	17.	16.	15.	14.	13.	12.	Į.	5	10	9	.∞	7.	6.	5	4.	ω	1.		_		o No
		-					u	Ş (	71	7	47		,		<b>3</b>	7 5	7	P :	Po	D,			Col No.
							-	C 4	C,	C.	5	4	`	,4	ي) د		5 6	٦	Ç	<u></u>			Col type
								0]:	= 4:	g 1, 7, 11	8.1"	-	- 6	8.1	- .	3/01/3/	1. 10		باً. د لا	4.8	-	Spec.	Heig
							1.3	01.01.	8.0	パイ・プ	8-11/2"	7-1"	8479	-   - '		Jack 8	0 1 . 1	ء ( و	12.8	8'.52"		Actual	Height in ft
							4	3	<	4	~	1	\<	۷	_ ر ح	\ <	1			4	rods	No of	Steel
							2			<b>?</b>	<	√ .	. <	~	र	K	\ \ \	\	~	<u>_</u>	rods	Size of	Steel ( v or x)
							2	\ <			۷.	<	<	~	1	4	X	\ \ \		<u> </u>	***		Honeycombs
							<	\	K	\	<	۷.	<	<	~	1	2		\	۷		Side 1	Plumb
							人		. <	,	<u> </u>	<	<	Z	K	1	1	<		<		Side 2	Plumb (✓ or 🗙)
Yes No				1	٦	┧┌	┧┌╴	16	7/1	7	☑Yes □No	✓ Yes ☐ No	✓ Yes □ No	✓ Yes No	✓ Yes ☐ No		1	1/	7 [	✓ Yes ☐ No	column?	marked on	Reference level