Quality Co
Control Check Repot.
After Column
Stage: After Column Casting (villas)

Recommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR not required.	Checked By MD on MD Sign	Previous stage report no. 28438 Report filed and sign	Project Manager 16 Rombothor Sign .	Prepared by P. Sai Kum Sign PRLY	Company Sev (LLU) Project Sev	Block No. 16 Column No. C1
y after recheck by QC. oort to QC team. the QC report. ATR not required.	For filling	Report filed and signed by PM?	Date	Date	Phase	Sl. No.
μ-	Yes No	Yes UNO	6/12/17	41013	N	44587

Columns Position Check.

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab.
- Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1")
- Show diagonals for 20% of bays. (Tolerance 1.5"),
- Print an A3 size plan.

Columns Position Check Plan enclosed? Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it. Wes No

Slab Dimensions Check.

Notes:

- Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
- Show outer dimensions of slab. (Tolerance 2")
- Show length and width of balconies (Tolerance I") Show inner dimensions of ducts and lift well. (Tolerance 1")
- Show location of sunken slab.
- Print an A3 size plan.

)	Actual thickness of slab?	7	Specified thickness of slab?
	Yes No AH	closed?	Slab Dimensions Check Plan enclosed?
	TISTON WITH THE COLOR WITH MICHIGAN STREET	2. Circle each correct dimension with green colour. Circle each incollect difficultive with the contract with the contra	Circle cach correct dimension with
THE ISLUIT HEAT TO IT.	meron with red cololly and mention actual of	Cimal a sank impact dime	

Quality Control Check Repot. Stage: After Column Casting (villas)

Good NAvg. Bad
]Good [√Avg. [] Bad
High Medium. Low
Good Avg. Bad
No
☐ Good ☐ Good ☐ High ☐ Good ☐ Good ☐ JYes ☐ Jad

Columns height, plumb, steel & level marking check.

Notes:

- Mark v for correct or minor mistake which does not require correction
 Mark X for minor mistake that requires minor correction.
 Mark X for major mistake that requires correction by replacement or re-fixing.
 Mark X for major mistake that cannot be corrected.
 Tolerance: Plumb 0.25".
 Circle actual height of columns if level differs from specified height by more than I".

20.	19.	18.	17.	16.	15.	14.	13.	12.	11.	10.	9.		7.	6.	5.	4.	ų.	2.	1.		SNo
						とよ	かかか	かし	62	5	DJ	19	CZ	(2)	83	82	1.8	D 1	≥_		Col No.
						Cı	C	C1	7	C	22	40	64	01	Ç	7	1.0	2	5.2		Col type
						4.8	14.8	æ. 1.º.	Q. 4"	37	1. K.S	ـ بد تر	8.41	かず	8,4"	14:0	Stance	8.4.	Spacer	Spec.	Heig
						1.4.8	14.8	8-34	8: 21/15	8-71	81. 74	27.7.5	2	8-7-16	8,4,	81.71	Starrers	81.41	Storens	Actual	Height in ft
						\vee	<	<	<	<	<	<	<	<	<	<	<	<	\	No of rods	Steel (
						/	<	<	<	\	<	<	<	<	<	7	<	<	(Size of rods	Steel (v or x)
							ζ,			< ,	<	<,	<	<,	(,	<,	<	5	<		Honeycombs
						<	<	< '				<	<	<	<			<	<	Side 1	Plumb
			00			V	<	<	<				<	< <				<	7	Side 2	Plumb (or X)
	Yes No	☐ Yes ☐ No	□Yes □No	☐Yes ☐No	☐ Yes ☐ No	Nes □No	√Yes □No	Yes No	☐Yes ☐No	□Yyes □ No	□Yes □No	Yes □No	□Yyes □No	√Yes □No	Yes No	Yres No	Wes □ No	∏Yes □ No	UYes □No	column?	Reference level