	_
	! =
	12
	<u> </u> =
	Ξ
	<u>.</u>
	1
	<u>ا</u>
	ı≍
	ᄪ
	ΙΞ
	آ ا
	=
	_
	(.
	0
	0
	7
	7
	ity Control Check Repot.
	0
	١ō
	-
	•
	1
	1
	1
	•
	7
	-
	30
	ďΟ
	e
	Stage: After Colum
	75
	_
	=
	e
	→
	_
	€.
	0
	Ξ
	=
	=
	_
	1
	2
	12
	Ξ
	=
- 3	JQ.
	_
	7
	7
3	U
	2
	_
	-
	_
	Ξ

	Quality Control Check Repot.		Stage: After Column Casting	ing (Apartments)	
Block No.	US F(blocks)	Column No.	Drive way	Sl. No.	31893.
Company	vista Inmes	Project	Saylo Halves	Phase	ì
Prepared by	S-SUMAL YELWARD Sign	Sign		Date	39/8/18
Project Manager	T Madhu	Sign	Mayany	Date	30/8/18
Previous stage report no.	ο.	31183	Report filed and signed by PM?		Yes No
Checked By MD on		MD Sign		For filling	☐ Yes ☐ No
Recommendation: Stop further work. Stop further work. Proceed with further Proceed with further	commendation: Stop further work. Submit ATR on QC report Stop further work. Proceed with work after s Proceed with further work only after making. Proceed with further work. ATR not required	port to QC team. Preser submitting ATR ing corrections poin ired.	scommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR not proceed with further work. ATR not required.	y QC. ATR not required.	
Columns Position Check Notes: I. Inspection should be done 2. Prepare Columns Position	umns Position Check. S: Inspection should be done after casting of column Prenare Columns Position Check Plan as follows:	s at each stage and befor	umns Position Check. es: Inspection should be done after casting of columns at each stage and before starting centering works for each Prenare Columns Position Check Plan as follows:	each slab.	
a. Divide blocks ib. Show size and	Divide blocks into smaller sub-blocks. Show size and orientation of columns. (Tolerance 0.5")	olerance 0.5")			
 c. Show inner – it d. Show diagonal 	Show inner – inner space between columns. (Tolerance 1") Show diagonals for 20% of bays. (Tolerance 1.5")	ns. (Tolerance 1") nce 1.5")			
e. Print an A3 size plan.	e plan.	ž			

Slab Dimensions Check.

Columns Position Check Plan enclosed?

Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it.

olumns Position Check Plan enclosed?

| Yes | No

Prepare Slab (or plinth beams) Dimensions Check Plan as follows:

Show outer dimensions of slab. (Tolerance 2")

Show length and width of balconies (Tolerance 1")
Show inner dimensions of ducts and lift well. (Tolerance 1")

Show location of sunken slab.

Print an A3 size plan.

Specified thickness of slab?	Slab Dimensions Check Plan enclosed?	2. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention
ZP	NA.	correct dime
Actual thickness of slab?	□Ycs □No	ension with red colour and mention actual dimension next to it.

Quality Control Check Repot. Stage: After Column Casting (Apartments)

Quality of centering, rod bending and concreting.	
Quality of centering, rod bending and concreting?	☐Good ☐ Avg. ☐ Bad
Quality of starters?	☐ Good ☐Avg. ☐ Bad
Number and size of honey combs?	☐ High ☑ Medium. ☐ Low
Are the honey combs is slab and columns packed?	☐ Good ☐ Avg. ☐ Bad
Number of beams that are sagging, bulging, caved or deflected in the slab by more than 1"	•
Have 6 cubes each for columns and slab casted and numbered for testing?	☐Yes ☐ No
Remarks:	
Curing.	
for curing made on slab? NA Yes	
Bund size is less than 100 sft? No No Yes No	
Drum (200 lts) provided for curing?	
Gunny bags used for column curing?	
Distance of tap from furthest distance that requires curing. (max permitted 100')	,
Frequency of curing in number of times a day (enquire from labourers)	a times
Is the pressure in the curing pipe more than 15' head?	
Quality of infrastructure for curing.	Bad
Remarks:	

Quality Control Check Repot. Stage: After Column Casting (Apartments)

Columns height, plumb, steel & level marking check.

- Mark v for correct or minor mistake which does not require correction
 Mark X for minor mistake that requires minor correction.
 Mark XX for major mistake that requires correction by replacement or re-fixing.
 Mark XX for major mistake that cannot be corrected.
 Tolerance: Plumb 0.25".
 Circle actual height of columns if level differs from specified height by more than 1".

17.	16.	15. 0	1.4. O	13. O	12. 0	111.	10.	9. A	8. A	7. A	6. A	5. A	4. A	3.	2.				S No Col
)			1			1			1	1	1	7	7	P.F			Col No. Col type
	1	o3_c	_,	(80	ر می		0.	0, 1,00	09 ,0 1-A-1	\$.	P, 2,	8	ر دی	χο, χο,	20,	ρ. 28.		Spec.	Height in ft
	,	8,00,	8-8,	8-8,	\$. -0,	8	S) S)	(S)	8,	20. (0)	8-9,	8.8	8,7,	4, 8,	8-4, 8,	8.8		Actual	t in ft
		(ς	((((ς	(٢	((ζ	(ς	(rods	No of	Steel (v or x)
		(ς	ζ	(((((ς	((ζ	(((rods	Size of	(or X)
		((((((((1	(ς	(ζ	(ς			Honeycombs
		((((<	(ζ	((Ç	C	<	((5		Side 1	Plumb (
		(ſ	((\ 	(<	((((ς .	(ζ		Side 2	Plumb (or x)
Yes No	☐ Yes ☐ No	Yes No		Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	Yes No	∠Yes □No	Yes No	Yes No	Yes No	∠Yes □No	∠Yes □No	column?	marked on	Reference level