	Quality Control Check Repot		Stage: After Column Casting (ting (Apartments)	
Block No.	D-22 528 flots	Column No.	0	Sl. No.	28306
Company	14-13E	Project	Pmr-B	Phase	
Prepared by	P. for Euner	Sign	Red	Date	78/10/17
Project Manager	Kishipah Kun	Sign	, j	Date	28/10/17
Previous stage report no.	no.		Report filed and signed by	d by PM?	☐ Yes ☐ No
Checked By MD on		MD Sign		For filling	Yes No
Recommendation: Stop further work. Stop further work. Proceed with furth Proceed with furth		report to QC team. Profier submitting ATR cking corrections point uired.	Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR not required.	y QC. ATR not required.	
Columns Position Check Notes:	<u>eck</u>			7 77	
Inspection should be done after Inspection Character Inspection Should be done after Inspection Character Inspection Should be done after Inspection Should be done after Inspection Should be done I	Prepare Columns Position Check Plan as follows: a. Divide blocks into smaller sub-blocks. b. Show size and orientation of columns. (Tolerance 0.5") c. Show inner – inner space between columns. (Tolerance 1") d. Show diagonals for 20% of bays. (Tolerance 1.5") e. Print an A3 size plan.	ins at each stage and before: Tolorance 0.5") nns. (Tolerance 1") ance 1.5")	Prepare Columns Position Check Plan as follows: a. Divide blocks into smaller sub-blocks. b. Show size and orientation of columns. (Tolerance 0.5") c. Show inner – inner space between columns. (Tolerance 1") d. Show diagonals for 20% of bays. (Tolerance 1.5") e. Print an A3 size plan.	each slab.	
3. Circle each correct dimension with green cc Columns Position Check Plan enclosed?	nension with green colour.	Circle each incorrect dime	red co	ntion actual dimension nex	t to it.
Slab Dimensions Check Notes:	<u>k</u>		LY Yes No		
Prepare Slab (or plinth a. Show outer d b. Show length a c. Show inner d d. Show location	Prepare Slab (or plinth beams) Dimensions Check Plan as follows: a. Show outer dimensions of slab. (Tolerance 2") b. Show length and width of balconies (Tolerance 1") c. Show inner dimensions of ducts and lift well. (Tolerance 1") d. Show location of sunken slab.	k Plan as follows: nce 2") lerance 1") well. (Tolerance 1")			
e. Print an A3 size plan. 2. Circle each correct dimension	ize plan. nension with green colour.	Circle each incorrect dime	e. Print an A3 size plan. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it.	ntion actual dimension next	to it.
Specified thickness of slab?	k Plan enclosed?		✓Yes □No		
specified injekness of stab?	Siab? L.I.	>	Actual thickness of slab?	6?	

Quality Control Check Repot. Stage: After Column Casting (Apartments)

Quality of centering, rod bending and concreting.)
Quality of centering, rod bending and concreting?	Good Avg. Bad
Quality of starters?	☐ Good [Avg. ☐ Bad
Number and size of honey combs?	☐ High Medium. ☐ Low
Are the honey combs is slab and columns packed?	☐ Good [v] Avg. ☐ Bad
Number of beams that are sagging, bulging, caved or deflected in the slab by more than 1"	
Have 6 cubes each for columns and slab casted and numbered for testing?	√Yes ☐ No
Remarks:	
Curing.	
Bunds for curing made on slab?	
Hund size is less than 100 sft? ☐ No	
Drum (200 lts) provided for enring?	
Ginning halps used for column curing?	
Distance of tap from furthest distance that requires curing. (max permitted 100')	The state of the s
Frequency of curing in number of times a day (enquire from labourers)	TO THE WHOLE CONTROL OF THE PARTY OF THE PAR
Is the pressure in the curing pipe more than 15' head?	7 - 1997 W. H. W.
Quality of infrastructure for curing.	Bad
Remarks:	
	The state of the s

Quality Control Check Repot. Stage: After Column Casting (Apartments)

Columns height, plumb, steel & level marking check.

- Mark \checkmark for correct or minor mistake which does not require correction Mark \times for minor mistake that requires minor correction.

 Mark \times for major mistake that requires correction by replacement or re-fixing.

 Mark \times \times for major mistake that cannot be corrected.

Tolerance: Plumb 0.25".

Circle actual height of columns if level differs from specified height by more than 1".

17.	16.	15.	14.	13.	12.	 	, j	,g)	7	G.	5.	4.	3.	2.	1.			S No
•	-)	})	**	,			•	-	})		}	•			Col No.
CV	6	(5	Cr	CY	7	CY	Cr	ر بر		(Ł	5	CS	CS	C.	63	77		_	Col type
"11t's	\$ 41 "	8, 4112"	117 18	いったう	8- 7- FI	21413	170 to 13	5.44.	50 41 12		いたる	S. 4 17.	8,41,1	11/10/18	100 , 1 - 1	114.8		Spec.	Heig
\$1.811	81.511	(1.h. B	8:31	8-81	₩	×- %::	8-8u	8,411		20.	رين		8-61	1.6.8	8,511	8.811		Actual	Height in ft
<	<	`\	5	V	<	<	ζ,	<	<	<,	5	<	5	<	<	<	rods	No of	Steel (
	`\	<	<	<	<	<	<	< .	K	<	<	<	\	/	<	<	rods	Size of	Steel (v or x)
<	5	5	<	<	1	V		ζ,	7	7	5	<	\	\	\	7			Honeycombs
	<i>\</i>			<	<	<u> </u>	<	<	<	<	<u> </u>	~	/	<	/	`		Side 1	Plumb
< (`,	<	/	/	<u> </u>		\	<	<	\		5	<	\	/		Side 2	Plumb (vor x)
□Yes □No	□Yyss □ No	☑Yes □No	No □No	Yes □No		□⁄yes □No	□Vres □No	Yes No	∏Yes □No	√Yes □No	ŊŶes □No	□Yyes □No	□XYes □No	L√Yes □No	L√Yes □No	☐Yes ☐No	column?	marked on	Reference level

Quality Control Check Repot. Stage: After Column Casting (Apartments)

					Ţ		Γ		!			T -		ľ			Γ	Γ						70
39.	38.	37.	36.	35.	34.	33	32.	31.	30.	29.	28.	27.	26.	25.	24.	23.	22.	21.	20.	19.	18.			S No
)	١	1	\))]	\				3)	1	1	1)	}	})	J	}			Col No.
\$	(%	CV	\$	2	\$	CX	2	C B	7	,, ,,	Cr	CK	છ	C5	CY	Cr	(5	Ç	7	50	CL			Col type
8:712"	8-411:	17114.8	マナデ	ペナント	からよう	17:4:18	1314.8	8.416	1.1 1.10	1 2 m 1 m 1 m 1 m 1 m 1 m 1 m 1 m 1 m 1	1 = C	1.21120	8.410	8.4112	1. J. T. 1. 8	8.711	8.411	11.6.8	8.7112	8.4 101	8.711.		Spec.	Heigh
8.8"	8 -5 "	8 . 8 .	8-84	8: 7"	8-21	8 8 "	87.8.	81-4"	81.811	81.87	8-7"	8°84	R. 4.1	81.5.1	8-811	8 284	E). 4"	18,18	30	81.51	8.8		Actual	Height in ft
<	<	<	<	<	5	<	<	ζ,	V		\		7			<	\	5	7	7	7	rods	No of	Steel (
<		<	5	<	<	<	7	۲,	۲.	<,	<	<	5	<	5	<	<	, <	,	<	<	rods	Size of	Steel (or x)
<	7	7	1	5	\		5	\	<	7	<			<	<	<	5	<	<	<			•	Honeycombs
	5	<	5	7	<	<	7		1	\	1	<	7	<	7	7	1			5	5	Order 1	Side 1	Plumb (
	5	5	<	<		<	<	<	<u> </u>	<	<	1/3	<			< '	\	< \		5	<	0100	Side 2	Plumb (v or x)
□Xes □No	JYes □No	□Yes □No	√Yes □ No	NYes □No	YYcs □ No	□Yes □No	☐Yes ☐ No	√Yes □No	NYes □No	√Yes □No	LYYes □No	√Yes □No	□Yes □No	□YYes □No	□Yes □No	□Yŕes □No	√Yes □No	□ Yes □ No	☑Yes □No	∏Yes □No	∏Yes □No	column?	marked on	Reference level

Quality Control Check Repot. Stage: After Column Casting (Apartments)

61.	60.	59.	58.	57.	56.	55.	54.	53.	57.	<u> </u>	50.	49.	48.	47.	46.	45.	44.	43.	42.	41.	40.		S No
					1	J	١				,)	1	1	J	ſ	-	1))	\		Col No.
					Cr	Cz	5	C.S	611	(;	(6	Cr	か	5	۲۹	CS	(8)	сҸ	4	4	くと		Col type
				54700	114.8	Q. u.l.	8,200	8.712	5 - 1 - 1 · 1	6.411	Q-41/2"	8-700	8,710	1.1.4.8	8-4 1/1	114.8	8-4 11	8.415	さたる	8-4-8	1.4.8	Spec.	Heigh
				(\$. \$.	8,41	8.4.1	81-8"	(°,	1.10	5.5.1	چە	01.81	00	000	1	81511	8.51)	8.8.1	8,811	8,3.	Actual	Height in ft
				8	\ <u></u>	1	<	· ·	ς,	ζ.	ζ.	<	5	<	5	/	/	?	<	<u></u>	<	rods	Steel (
					<u> </u>	\ \	<	<	<	ζ,	<	V	<	~	<u> </u>	7	7	1	\	<	<	Size of rods	Steel (or x)
					· · ·	V	5	<	ζ,			V	<	\	ζ'		\	5	<	5	ς,		Honeycombs
37					/	<u></u>	<	<	<_	/	<	1	/	/	~	7	<	5	5	5	5	Side 1	Plumb
					7	/	\	<	ζ,	/	\	7	7	1	~	<	_	7	7	5	7	Side 2	Plumb (v or x)
☐ Yes ☐ No	☐Yes ☐No	□Yes □No	☐ Yes ☐ No	∏Yes ∏No	Yes No	No □No	NO Des	□Yes □No	□X es □ No	ŊŶes □No	∏Yes □No	□Xes □No	☐Yyes ☐ No	□Xyes □ No	Yes No	□Yyes □ No	☐Yyes ☐No	☐Yes ☐No	Yes No	∏\Wes □ No	UYes □No	column?	Reference level