/

### Quality Control Check Repot. Stage: After Column Casting (villas)

Block No.	08	Column No.	0	SI. No.	32526
Company	Vac (42p)	Project	VoC	Phase	
Prepared by	4 Branch	Sign	S MA	Date	31/12/18
Project Manager	n. Guerah	Sign		Date	31/12/18
Previous stage report no.	0.	31673	Report filed and signed by PM?	d by PM?	✓Yes □No
Checked By MD on		MD Sign		For filling	☐Yes ☐No
Recommendation:  Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck be Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. Proceed with further work. ATR not required.	commendation: Stop further work. Submit ATR on QC report Stop further work. Proceed with work after s. Proceed with further work only after making Proceed with further work. ATR not required	scommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR n Proceed with further work. ATR not required.	eed only after recheck be QC report to QC team. I out in the QC report. 1	y QC. ATR not required.	
Columns Position Check.	<del>\</del>	<b>at</b>			

Notes:

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab.
- Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1") Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.
- each correct dimension with Marie Cimile

Clah Dimonsions Ob 1	Columns Position Check Plan enclosed?	2. Circle each correct difficultions of with green colour. Circle each incorrect dimension with red colour and men
	✓ Yes	correct dimension with red colour and mention actual dimension next to it.

#### Siab Dimensions Check.

Notes:

- 1. Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
- Show length and width of balconies (Tolerance 1") Show outer dimensions of slab. (Tolerance 2")
- Show inner dimensions of ducts and lift well. (Tolerance 1")
- Show location of sunken slab.
- Print an A3 size plan.
- <u>S</u> i,

•	Actual thickness of slab?	Specified thickness of slab?	Spec
			}
	L Yes L No 2,5	STAD CHILDING CHECK FIAH EHGIOSEG!	Ordo
CHARLES OF THE PARTY OF THE		noncione Charle Dlan and cards	2127
dimension next to it	nsion with red colour and mention actual	2: Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and men	4.

# Quality Control Check Repot. Stage: After Column Casting (villas)

Quanty of centering, fod bending and concreting.	
Quality of centering, rod bending and concreting?	Good Avg. Bad
Quality of starters?	☑ Good ☐ Avg. ☐ Bad
Number and size of honey combs?	N.A   High   Medium.   Low
Are the honey combs is slab and columns packed?	Good Avg. Bad
Number of beams that are sagging, bulging, caved or deflected in the slab by more than 1"	than 1"
Have 6 cubes each for columns and slab casted and numbered for testing?	✓ Yes □ No
Remarks:	
Bunds for curing made on slab?	☐ Yes ☐ No N.A
Bund size is less than 100 sft?	Yes No
Drum (200 lts) provided for curing?	☐ Yes ☐ No —
Gunny bags used for column curing?	☐Yes ☑No
Distance of tap from furthest distance that requires curing. (max permitted 100')	70-0":
Frequency of curing in number of times a day (enquire from labourers)	2times
Is the pressure in the curing pipe more than 15' head?	√Yes □No
Quality of infrastructure for curing.	
Remarks:	Good ☐ Avg. ☐ Bad

## Columns height, plumb, steel & level marking check.

- Mark  $\vee$  for correct or minor mistake which does not require correction Mark  $\times$  for minor mistake that requires minor correction.

  Mark  $\times$  for major mistake that requires correction by replacement or re-fixing. Mark  $\times$  for major mistake that cannot be corrected.

  Tolerance: Plumb 0.25".
- Circle actual height of columns if level differs from specified height by more than 1".

20.	19.	18.	17.	16.	15.	14.	13.	12.	11.	10.	9.	&	7.	6.	5.	4.	3.	2.	1.		S No
									P3	<b>ט</b>	£,	67	C.	48	B2	Āģ	A.	γ,	<b>&gt;</b>		Col No.
	66 as some					38 00 00			65		R	R	C2-	(3	4	C	Ō	3	Ω		Col type
		154			30 de la constante de la const			(100 CO)	8-11	8-4"	8-1"	8-1"	Strives	8-41	Q 1 12	Stowed	8-411	8-4"	1. E-3	Spec.	Heigl
									8-011	8-34	8-111	8-11/211	فحنفاذ	81-1"	8-2"	Sains	8.5.8	8-5"	11-18	Actual	Height in ft
									4	~	<	~	۷.	<	<u> </u>				2	No of rods	Steel (
									4	~	×	X.	<	Ł	<	<	<u> </u>	Į,	<	Size of rods	Steel ( v or x)
									1	~	\ \	۷,	<	X	Ų,	<	<	4	<		Honeycombs
									<	<	~	<	×.	,	ζ,	•	· ·	*	4	Side 1	Plumb
									<	<	<	<	`	~	٠,	1	<	· ·	X	Side 2	Plumb ( v or x)
Yes No	☐Yes ☐No	☐ Yes ☐ No	☐ Yes ☐ No	☐Yes ☐No	☐Yes ☐No	☐ Yes ☐ No	Yes No	☐Yes ☐No			1		Yes No	Yes No	Yes No		∐Yes No	1	☐ Yes No	marked on column?	Reference level