n O
ality
Co
lity Control Check Repot.
1eck
Re
ot.
Stag
re: /
fte
Ω.
lum
n C
ot. Stage: After Column Casting (villas)
A) BI
illas

Block No. 196	Column No.	02	SI, No.	32477
Company Voc (114)	Project	You	Phase	
Prepared by	Sign	V-Swhit	Date	27/12/18
Project Manager A. Salvesh	Sign	CAN.	Date	27/12/118
Previous stage report no.	32361	Report filed and signed by PM?	ed by PM?	∠Yes ∐No
Checked By MD on	MD Sign		For filling	☐Yes ☐No
Recommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR not required.	report to QC team. Pro after submitting ATR o aking corrections point quired.	ceed only after recheck n QC report to QC tean ed out in the QC report.	by QC. ATR not required.	

Columns Position Check. Notes:

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab. Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolcrance 1")
- Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.
- valour Circle auch in

Yes No	Columns Position Check Plan enclosed?
CCI (IIII) 100 MIII LEGI COLOUI SHA INCHIDEN ACHAIL AND AND INCHIDENCE IN INCHIDENCE I	3. Cucle each correct dimension with green colour. Circle each incorrect dimension with red colour and much

Slab Dimensions Check.

- 1. Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
- Show outer dimensions of slab. (Tolerance 2")
- Show length and width of balconies (Tolerance 1") Show inner dimensions of ducts and lift well. (Tolerance 1")
- Show location of sunken slab.
- Print an A3 size plan.

5" Actual thickness of slab? 5"

Quality Control Check Repot. Stage: After Column Casting (villas)

☐ Good ☐ Avg. ☐ Bad
☐ High ☐ Medium. ► Low
Good ✓ Avg. ☐ Bad
Number of beams that are sagging, bulging, caved or deflected in the slab by more than 1"
✓ Yes □ No
✓ Yes □ No
Yes No
]Yes □No —
√Yes □No
301011
stores
✓ Yes □ No
√Good ☐ Avg. ☐ Bad

Columns height, plumb, steel & level marking check. Notes:

Mark v for correct or minor mistake which does not require correction

Mark X for minor mistake that requires minor correction.

Mark XX for major mistake that requires correction by replacement or rc-fixing.

Mark XXX for major mistake that cannot be corrected.

5. Tolerance: Plumb 0.25".

6. Circle actual height of columns if level differs from specified height by more than 1".

SNo 20 12. 19 8 17. 16. 9 ∞ 5 14 13 10 6 w 12 Col No. 47 **P**3 12 To 25 22 Ñ **D** 27 A Col type 7 22 5 4 2 C2 7 2 7 63 C2 Staro 8-4-1 1 to 18 14.38 8-11 14.78 Spec. Slaiss 11 12-18 8-4" 12-18 *#-18 Height in ft 8-9" Stairs Steins 12 8-4" 8-612" 8-81/2 8-6= 8-8" Actual 8-41/2 No of rods Steel (✓ or ×) < rods Size of Honeycombs Side 1 Plumb (or x) Side 2 < y Yes $\sqrt{\mathrm{Yes}}$ ✓ Yes Yes V Yes \sqrt{Y} es V Yes Yes ✓ Yes Yes marked on column? Reference level V Yes Yes]Yes Yes Yes] Yes]Yes Yes Yes Yes No LNo L No L No \square No LNo No No S No Zo Zo No No No Vo No No No