Quality Control Check Repot.

Stage: After Column Casting (villas)

Block No.	23	Column No.	0)	Sl. No.	32459
Company	Project Project	Project •)	sucretains	Phase	į
Prepared by	S. Kulder	Sign	- soupples	Date	26/12/18
Project Manager		Sign	1	Date	26/12/18
Previous stage report no.	no.	32024	Report filed and signed by PM?	d by PM?	√Yes □No
Checked By MD on		MD Sign		For filling	∏Yes ∏No
Recommendation: Stop further work. Stop further work Proceed with furtl Proceed with furtl	Recommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck I Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. Proceed with further work. ATR not required.	port to QC team. Procer submitting ATR or ing corrections pointe ired.		by QC. 1. ATR not required.	
Columns Position Check.	eck.				72.

Notes:

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab. Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1")
- Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.
- Circle each correct dimension with groon color Circle

Columns Position Check Plan enclosed?

Slab Dimensions Check.

Notes:

- Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
- Show outer dimensions of slab. (Tolerance 2")
- Show inner dimensions of ducts and lift well. (Tolcrance 1") Show length and width of balconies (Tolerance 1")
- d c Show location of sunken slab.
- Print an A3 size plan.
- Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it

Specified thickness of slab?	Slab Dimensions Check Plan enclosed?	2. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and men
Actual thickness of slab?	∏Yes ∏No _β β	mension with red colour and mention actual dimension next to it.

Quality Control Check Repot. Stage: After Column Casting (villas)

☐ Good ☐ Avg. ☐ Bad
☐ High ☐ Medium. ☐ Low
☐ Good ☐ Avg. ☐ Bad
☐ Yes ☐ No
]No No. 4
]No
No (
No
No
☐Good ☐ Avg. ☐ Bad

Columns height, plumb, steel & level marking check.

- Mark v for correct or minor mistake which does not require correction
 Mark X for minor mistake that requires minor correction.
 Mark XX for major mistake that requires correction by replacement or re-fixing.
 Mark XX for major mistake that cannot be corrected.
 Tolerance: Plumb 0.25".

Circle actual height of columns if level differs from specified height by more than 1".

20.	19.	18.	17.	16.	15.	14.	13.	12.	11.	10.	9.	.8	7.	6.	5.	4.	3.	2.	<u></u>			S No
				27	F. 60	T1	23	<i>D</i> ₃	P	53	Cs	()	BY	83	50	70	Ay	Az	A			Col No.
				<u></u>	C2	C2	C	C.	C2	C)	62	c)	CZ	ر)	CZ	Ĉ	C)_	ره	61			Col type
				d-u/2"	8-412"	81-7/2"	81-41/2"	81-41/21	81-1/211	8-7/21	8-7/2"	81-7211	81-4%"	81-7/21	Q-4/21	141-15	2/1-1/2"	8-1/2"	N . H . N	Tunning Tunning	Spec.	Heigh
				81-611	81-611	20-81	01-31	8)-51	81-64	81-611	8-611	01-711	1,4 - (8	0-71	21-13	8-6"	8-6"	0 L 4 =	8-6"		Actual	Height in ft
				<	(<	<	<	ς	<	7	ς	<	4	ς	<	(ζ.	(rods	No of	Steel (
				<	<	<	<	<	7	7	((ζ.	(,	(ς	ς.	ζ.	rods	Size of	Steel (or x)
				ζ	X	X	ď	(X	7	7	٨.	ζ	(7	7	X	(7			Honeycombs
					?	ζ	ζ	7	ζ	7	1	ζ	ς.	7	ζ	ζ	1	\	(Side 1	Plumb
				((7	ζ	(7	ζ	ζ	ζ.	ζ	r	7	ζ	7	ſ	7		Side 2	Plumb (✓ or ×)
☐ Yes ☐ No	☐Yes ☐No	☐Yes ☐No	☐Yes ☐No	Yes No	∠Yes □No	Yes No	☐Yes ☐No	∐Yes □No	☐Yes ☐No	Yes No	Yes No	☐Yes ☐No	Yes No	☐Yes ☐No	∏Yes □No	☐ Yes ☐ No	☐ Yes ☐ No	☐ Yes ☐ No	☐Yes ☐No	column?	marked on	Reference level