	Actual thickness of slab?		n enclosed?	Specified thickness of slab?
n actual d	red co	Plan as follows: ce 2") erance 1") well. (Tolerance 1") Lircle each incorrect dimens	es: Prepare Slab (or plinth beams) Dimensions Check Plan as follows: a. Show outer dimensions of slab. (Tolerance 2") b. Show length and width of balconies (Tolerance 1") c. Show inner dimensions of ducts and lift well. (Tolerance 1") d. Show location of sunken slab. e. Print an A3 size plan. Circle each correct dimension with green colour. Circle each incorrect	Slab Dimensions Check. Notes: 1. Prepare Slab (or plinth beams a. Show outer dimension b. Show length and wid c. Show inner dimension d. Show location of sun e. Print an A3 size plan 2. Circle each correct dimension Slab Dimensions Check Plan
IN NORMAL CHIEVELDS OF THOSE TO IT.	Yes No		ck Plan enclosed?	2
n actual d	hispection should be done after easting of columns at each stage and before starting centering works for each slab. Prepare Columns Position Check Plan as follows: a. Divide blocks into smaller sub-blocks. b. Show size and orientation of columns. (Tolerance 0.5") c. Show inner—inner space between columns. (Tolerance 1") d. Show diagonals for 20% of bays. (Tolerance 1.5") e. Print an A3 size plan. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actured to the colour and mention actures.	is at each stage and before solicitance 0.5") ins. (Tolerance 1") ince 1.5")	Inspection should be done after casting of columns at each stage and Prepare Columns Position Check Plan as follows: a. Divide blocks into smaller sub-blocks. b. Show size and orientation of columns. (Tolerance 0.5") c. Show inner – inner space between columns. (Tolerance 1") d. Show diagonals for 20% of bays. (Tolerance 1.5") e. Print an A3 size plan. Circle cach correct dimension with green colour. Circle each incorre	Notes: 1. Inspection should be done afte 2. Prepare Columns Position Che a. Divide blocks into sn b. Show size and orients c. Show inner – inner sp d. Show diagonals for 2 e. Print an A3 size plan. 3. Circle cach correct dimension
			6.7	Columns Position Check
γC.	Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR not required. Proceed with further work. ATR not required.	Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck I Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. Proceed with further work. ATR not required.	commendation: Stop further work. Submit ATR on QC report Stop further work. Proceed with work after support Proceed with further work only after making a Proceed with further work. ATR not required.	Recommendation: Stop further work. Stop further work. Proceed with furth
For filling	Fo	MD Sign		Checked By MD on
y PM?	Report filed and signed by PM?	スタストイ	no.	Previous stage report no.
Date	(bod) Di	Sign	Radheshyam	Project Manager
Date	7. (Col.) Di	Sign	P. So Kun	Prepared by
Phase	Nelaw estate Ph	Project	Killomi esta	Company
SI. No.	SI.	Column No.	\$ 80	Block No.

Quality Control Check Repot. Stage: After Column Casting (villas)

Quality Control Check Repot. Stage: After Column Casting (villas) rod bending and concreting

Quality Control Check Repot. Stage: After Column Casting (villas)

Columns height, plumb, steel & level marking check. Notes:

- Mark v for correct or minor mistake which does not require correction

 Mark x for minor mistake that requires minor correction.

 Mark x for major mistake that requires correction by replacement or re-fixing.

 Mark x x for major mistake that cannot be corrected.

 Tolerance: Plumb 0.25".

	`
_	١
Ì	1
ircle :	
22	
5	1000
a	
ne	•
ij	
11	
ΩŢ	,
actual height of colum	
ш	
I	
1S 1	
lumns if te	,
ns if level d	
el e	
Q1I	
Tel	i
differs fron	
0.1	,
H	
sp	
ecı	
ciffed f	5
ď	
ne	
8	•
111	
у	
m	
ole	
Circle actual neight of columns it level differs from specified height by more that	
an	
-	1
	•

20.	19.	18.	17.	16.	15.	14.	13.	12.	11.	10.	9.	œ	7.	•	<i>.</i>	-	ند:	iэ	1.		S No
																্ ২	ج ت	700	64		Col No.
																()	2	C1	(1		Col type
									2							28.7.1.4.1	STATES	2717	8.311	Spec.	Heigh
					1002		500-002				200					8.4.1	ないかい	8:4"	8.4.	Actual	Height in ft
																<	<	<	<	No of rods	Steel (
															8	~	<	<	<	Size of rods	Steel (v or x)
					0.0							3				<	<	<	7		Honeycombs
														_		<	1	<	7	Side 1	Plumb
																<	\	<	<	Side 2	lumb (✓ or ×)
Yes No	☐ Yes ☐ No	☐Yes ☐No	☐ Yes ☐ No	☐ Ycs ☐ No	☐ Yes ☐ No	✓ Yes □ No	☐Yes ☐ No	Yes No	□Yes □No	marked on column?	Reference level										