	Commence of the second of the		Sagge: Guer Column Casting (Apartments)	e (Apartmen	IS.
- Lander Control of the Control of t	,			Ci. No.	
Block No.	F-1006 Jacos	Colding ino.	01	Dhase	30400
Company	Vista Hones	Project	vista Holmes	Lilasc	
Prepared by	D. MINIACIAN	Sign	200	Date	01/06/18
Project Manager	_	Sign	Mulum	Date	01/06/18
Previous stage report no.		30(5)	Report filed and signed by PM?	by PM?	
Checked By MD on		MD Sign		For mang	
Recommendation: Stop further work. Stop further work. Proceed with further	Submit ATR on QC re Proceed with work af er work only after mak	Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck be Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report.	ommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR not required.	y QC. \TR not require	đ.
Columns Position Check.	Proceed with further work. Alk not required, umns Position Check.	11 cd.			
Notes: 1. Inspection should be d 2. Prepare Columns Posit	ss: Inspection should be done after casting of column Prepare Columns Position Check Plan as follows:	ns at each stage and before :	es: Inspection should be done after casting of columns at each stage and before starting centering works for each slab. Prepare Columns Position Check Plan as follows:	each slab.	
5 10	Divide blocks into smaller sub-blocks. Show size and orientation of columns. (Tolerance 0.5") Show inner – inner space between columns. (Tolerance 1")	Tolerance 0.5") ans. (Tolerance 1")		×	
d. Show diagonals for 29 e. Print an A3 size plan.	Show diagonals for 20% of bays. (Tolerance 1.5") Print an A3 size plan.	ance 1.5")		ention actual dimer	actual dimension next to it.
3. Circle each correct dimension with green co Columns Position Check Plan enclosed?	ck Plan enclosed?	Circle each montest amo	Circle each correct dimension with green colour. Circle each incorrect dimension with green colour. Circle each incorrect dimension. When the control of the		
Slab Dimensions Check.	<u>k. </u>				
1. Prepare Slab (or plint) a. Show outer d	Prepare Slab (or plinth beams) Dimensions Check Plan as follows: a. Show outer dimensions of slab. (Tolerance 2")	k Plan as follows: nce 2'')			
b. Show length c. Show inner d	Show length and width of balconies (Tolerance 1) Show inner dimensions of ducts and lift well. (Tolerance 1") Show location of sunken slab.	well. (Tolorance 1")			
e. Print an A3 size plan.	ize plan. mension with green colour	Circle each incorrect dime	e. Print an A3 size plan. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention		actual dimension next to it.
2	ck Plan enclosed?	Z.A	∐Yes ∐No		
Specified thickness of slab?	slab?	2 P	Actual thickness of slab?	**	2 ア

Quality of centering, rod bending and concreting.	7 T () () () () () () () () () (
Quality of centering, rod bending and concreting?	Good Avg. Bad
Quality of starters?	☐ Good ☐ Avg. ☐ Bad
Number and size of honey combs?	☐ High ☐ Medium. ☐ Low
Are the honey combs is slab and columns packed?	Good Avg. Bad
Number of beams that are sagging, bulging, caved or deflected in the slab by more than 1"	
Have 6 cubes each for columns and slab casted and numbered for testing?	□Yes □ No
Remarks: (1) Instead of (3-3) Magking they some (4-4)	
C	
Curing.	
Bunds for curing made on slab? NA Yes No	
Bund size is less than 100 sft? NA Yes No	7
Gunny bags used for column curing?	-
Distance of tap from furthest distance that requires curing. (max permitted 100')	٥
e from labourers)	& Jimos
ore than 15' head?	
Quality of infrastructure for curing.	Bad
Remarks:	

Oplinging hair of make about the strong and one of sale.

Mark × for minor mistake that requires minor correction.

Mark × for major mistake that requires minor correction.

Mark × for major mistake that requires correction by replacement or re-fixing.

Mark × x for major mistake that cannot be corrected.

Tolerance: Plumb 0.25".

Circle actual height of columns if level differs from specified height by more than 1".

	Т	Τ	Ţ	T	Т	Т	Т	Γ.			1		_	T'-	1	T	Т-		<u> </u>
17.	16.	15.	14.	13.	12.		10.	9.	∞	7.	6.	5.	4:	ယ	2.	-			S No
-)	1	}	}	1)	3	j	١	1))	1)	1	-			Col No.
C4-	C4	S	S	C4	3	CS	04	CA	Cs	C	() ()	Ca	C3	C3	C9	Ca			Col type
1-91	11-91	11-811	11-81	11/2 01	11.55	11-81	11-91	11-9-	11.05	11/5/	11-8-	11-81	11-91	(1)-91	11-8-	11-8-		Spec.	Heig
コーニッ	11-01	11,20,1	11-3,	11-4	11-0-	1-0:	1-4	11-6	1.0.	11-4	10-11	1/20/	11-11-	11-6"	=-	11/0/		Actual	Height in ft
((ς	<	((ς.	ς	ς	((ς	ς	<	ς .	ς .	ς.	rods	No of	Steel (
ζ	Ç	(ζ	ς.	ζ).	(٢	(5	(۲	ς	۲	ς	ζ	rods	Size of	(or X)
?	((ζ	>	(\	(.(((ζ	ς	(ζ.	(\			Honeycombs
,	3	ζ	(((7	((((۲	((ς .	((Side 1	Plumb
(1	(ζ	(((۲	((<	ζ	ς	<	((ς .	-	Side 2	Plumb (or x)
Yes □No	∠ Yes □ No	☐ Yes ☐ No	Yes □No	✓ Yes ☐ No	∠Yes □No	☐ Yes ☐ No	∠Yes ☐No	☐Yes ☐No	∠ Yes No	⊢ Yes □ No		☑Yes □No	∠Yes □No	∠Yes □No	☐ Yes ☐ No	∐Yes □No	column?	marked on	Reference level

113 120 20 21 21 21 22 22 23 23 24 24 25 25 25 27 27 30 31 31 31 32 33 33 33 33 33 33 33 33 33 33 33 33
18. 19. 22. 21. 22. 23. 23. 23. 23. 23. 23. 24. 27. 27. 27. 27. 27. 27. 27. 27. 27. 27
11-12-12-12-12-12-12-12-12-12-12-12-12-1
CCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCC
Size of the state
Side 2 manus of the contract o