15
Ę
=
ATITE
DILLI.
2
_
IÈ
ΙĒ
⊊
rot Check Repot.
١ĕ
-
1
V.
급
垣
œ
h-
16
7
r
r Co
After Colu
r Colun
r Column
r Column (
r Column C:
r Column Cas
Stage: After Column Casti
r Column Castin
r Column Casting
ng
ng
r Column Casting (villa
ng

זון וונ					
Block No.	114	Column No.	40	SI. No.	2 F.> U.S.
Company	rilgie Estet	Project	vilage estates	Phase	() ()
Prepared by	S. Kuldert	Sign		Date	0/2/2010
Project Manager	Madhusudhan Sign	Sign	N. m. A. M. Date	Date	10/06/2010
Previous stage report no.	no.	1	Donat filed and at	11 70 70	14/00/200
Trotxons smgc report	IIO.	30354	Report filed and signed by PM?	1 by PM?	☐Yes ☐No
Checked By MD on		MD Sign		For filling	☐Yes ☐No
Recommendation: Stop further work.	ecommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC.	port to QC team. Proce	ed only after recheck b	y QC.	
Stop further work. Proceed with furth Proceed with furth	Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR Proceed with further work. ATR not required.	er submitting ATR on ing corrections pointed red.	QC report to QC team. lout in the QC report. A	TR not required.	
Columns Position Check	(C)				

Notes:

- Prepare Columns Position Check Plan as follows: Inspection should be done after easting of columns at each stage and before starting centering works for each slab.
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner—inner space between columns. (Tolerance 1") Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.

Columns Position Check Plan enclosed? Slab Dimensions Check. 3. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it. Yes

Notes:

- 1. Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
- Show outer dimensions of slab. (Tolerance 2")
- Show length and width of balconies (Tolerance 1")
 Show inner dimensions of ducts and lift well. (Tolerance 1")
- Show location of sunken slab.
- Print an A3 size plan.
- Circle each correct dimension with oreen colour Circle 1

Specified thickness of slab? (1 / 5 / Actual thickness of slab? (1 / 5 / 1)	Slab Dimensions Check Plan enclosed? A Yes No	The state of the s
177	TISJON NEXT TO IT.	

Quality Control Check Repot. Stage: After Column Casting (villas)

Quality Control Check Repot. Stage: After Column Casting (villas)

Columns height, plumb, steel & level marking check. Notes:

- Mark \checkmark for correct or minor mistake which does not require correction Mark \times for minor mistake that requires minor correction.

 Mark \times for major mistake that requires correction by replacement or re-fixing. Mark \times \times for major mistake that cannot be corrected.

 Tolerance: Plumb 0.25".

Circle actual height of columns if level differs from specified height by more than 1".

20.	19.	18.	17.	16.	15.	14.	13.	12.	11.	10.	9.	8.	7.	6.	5.	4.	ÿ	2.	1.			S No
						De	7	2	0,	0.	2	Cy	C2	()	35 35	106	f)3	6	£.			Col No.
	۴.					()	(2	6	0	<u></u>	C 2	C2	S	5	0	C2	C2	0				Col type
3.00		i i				Slaw	Stark	8, 721	13 , 7/4°	B) 17/2"	B! #3"	01.36 1	E. 0.7"	CC_ 12.52 = 0	18 1 1 1 B	है.५% व	भू भारत	8, 11, 18	8,21,4		Spec.	Heigh
						straices	stairs	5.6	6 · u /. "	8'. 8"	O. 43	\$. \$.	8:4,1	ء ت م'	ශ _ු ය	CS . S	\$.c.	(3)	1 t. 8		Actual	Height in ft
						ζ	?	V	7	(7	١	(ζ.	7	۲	?	Z,	7	rods	No of	Steel (
						ζ	(7	1	(1	(((7	?		1.	7	rods	Size of	Steel (or x)
						7	5	~	?	~	Parameter	V	'بن	1	Ć	×	ス	1	7		,	Honeycombs
						V	ζ	۲	(ζ	<	~	4	~	\sim	7		Ĺ	(Side 1	Plumb
						1	((7	<		<	(?	((1	1		Side 2	umb (✓ or 🗙)
☐ Yes ☐ No	☐Yes ☐No	□Yes □No	□Yes □No	☐Yes ☐No	☐Yes ☐No	√Yes □ No	√Yes No	Yes No	∠Yes □ No	☑ Yes ☐ No	∐Yes □No	✓ Yes □ No	Yes No	✓ Yes ☐ No	☐Yes ☐No	☐ Yes ☐ No	☐Yes ☐No	☐Yes ☐No	☐ Yes ☐ No	column?	marked on	Reference level