Quality	Omn liter Cont
COHULOI	0
Quality Court of Check Vehor	Charle Dance
Stage: After Committee Casting (vinas)	Otomor Attac
Column	0
Casume	1
(VIIIAS)	C. III

Recommendation: Stop further work. Stop further work. Proceed with furth Proceed with furth	Checked By MD on	Previous stage report no.	Project Manager	Prepared by	Company	Block No.
commendation: Stop further work. Submit ATR on QC report Stop further work. Proceed with work after submoved with further work only after making a Proceed with further work. ATR not required.		no.	Accept	S. Kulder	VOC (LLP)	120
Recommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR n Proceed with further work. ATR not required.	MD Sign	31789	Sign	Sign	Project	Column No.
eed only after recheck l QC report to QC team d out in the QC report.		Report filed and signed by	A	Simpmis	UOC	02
by QC. ATR not required.	For filling	ed by PM?	Date	Date	Phase	SI. No.
	☐ Yes ☐ No	Ycs No	80/11/08	30/11/18	1	32244

Columns Position Check.

Notes:

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab. Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1")
- Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.

 Ich correct dimension w

2	\mathcal{C}	'n
2	Columns Position Check Plan enclosed	Chole each collect difficult with green colour. Chole each incollect diffiension with red colour and mention a
•	ositic	acm con
)	n Ch	Teer of
•	eck P	HSTERIE
	Check Plan en	DILM UC
	close	green
	1?	colour.
		. Circle
80		cach I
		ncorrec
		me arme
	1 Ves	A HOISU
	es	71th red
	Š	colou
		n pue
		nention
		actual
		dimen
53.		Sion no
		XI to It
33		
-		

Slab Dimensions Check.

Notes:

- Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
 a. Show outer dimensions of slab. (Tolerance 2")
- Show length and width of balconies (Tolerance 1")
- Show inner dimensions of ducts and lift well. (Tolerance 1")
- Show location of sunken slab.

	actual dimension next to it.	nsion with red colour and mention Yes No Actual thickness of slab?	e. Print an A3 size plan. 2. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention a Slab Dimensions Check Plan enclosed? Specified thickness of slab?	e. Print an A3 size plan. 2. Circle each correct dimension with green of Slab Dimensions Check Plan enclosed? Specified thickness of slab?
--	------------------------------	--	---	--

Quality Control Check Repot. Stage: After Column Casting (villas)

Quality of centering, rod bending and concreting?	Good Ave Rad
Quality of starters?	Good Avg. Bad
Number and size of honey combs?	☐ High ☑ Medium. ☐ Low
Are the honey combs is slab and columns packed?	☐ Good ☐ Avg. ☐ Bad
Number of beams that are sagging, bulging, caved or deflected in the slab by more than I'	1
Have 6 cubes each for columns and slab casted and numbered for testing?	✓ Ycs ☐ No
Remarks:	
Curing.	
Bunds for curing made on slab?	s No .
Bund size is less than 100 sft?	s No
Drum (200 lts) provided for curing?	No
Gunny bags used for column curing?	
Distance of tap from furthest distance that requires curing. (max permitted 100')	
Frequency of curing in number of times a day (enquire from labourers)	2 times
Is the pressure in the curing pipe more than 15' head?	□N ₀
Quality of infrastructure for curing.	Good Navg. Bad
Remarks:	

Columns height, plumb, steel & level marking check. Notes:

Mark v for correct or minor mistake which does not require correction
Mark X for minor mistake that requires minor correction.
Mark X for major mistake that requires correction by replacement or re-fixing.
Mark X X for major mistake that cannot be corrected.
Tolerance: Plumb 0.25".

Circle actual height of columns if level differs from specified height by more than 1".

							81-14 81-14 81-14 81-14	1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1	1, 1, 1, 2, 2, 2, 3, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4, 4,	1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1	
Q'.3"	81.31 81.31	8:31 8:31	81.3" 81.3"	81-31 81-31	81-31 81-31	81-31 81-31 81-31	81-31 81-31 81-31	81-31 81-31 81-31 81-31 81-41	81-31 81-31 81-31 81-41 81-41	81-31 81-31 81-31 81-41 81-41 11-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-	81-81-11 81-81-11 81-81-11 11-12-13
	(rods
(roc
											roc
											C C C C C C C C C C C C C C C C C C C
	(rods
\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	((((((((rods
	ζ	((((((((,	(((, ((((((((((((((((((((((((((