	_
-	\subset
	_
- 1	≂
1	=
- 1	=
	7
	~
	<u>`</u> -
1	9
	=
	▆
9	3
- 1	9
- 1	
- 1	\sim
- 1	
	=
	₾.
	☳
	\sim
	_
	Quality Control Check Repot.
	0
- 1	
- 1	ŏ
	=
	• .
	7.0
	V.
	Sta
	Stag
	Stage
	Stage:
	Stage:
3	Stage: A
	Stage: At
3	Stage: Aft
	Stage: Afte
	Stage: After
	Stage: After (
	Stage: After C
	Stage: After Co
	Stage: After Colu
	Stage: After Colu
	Stage: After Colum
	Stage: After Column
	Stage: After Column
	Stage: After Column (
	Stage: After Column C
	Stage: After Column Ca
	Stage: After Column Cas
	Stage: After Column Casti
	Stage: After Column Castir
	Stage: After Column Casting
	Stage: After Column Casting
	Stage: After Column Casting (
	Stage: After Column Casting (vi

Recommendation: Stop further work. Stop further work. Proceed with furth Proceed with furth	Checked By MD on	Previous stage report no.	Project Manager	Prepared by	Company	Block No.
Recommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR not required.		no.	Bala Mural: Krisha	G. RAJESH	KNM	50
eport to QC team. Proc fter submitting ATR on sing corrections pointed pired.	MD Sign	338 US	Sign	Sign	Project	Column No.
eed only after recheck QC report to QC team d out in the QC report.		Report filed and signed by	Charle	Elle.	Bloomdale	02
by QC. ATR not required.	For filling	ed by PM?	Date	Date	Phase	Sl. No.
	☐ Yes ☐ No	Yes No	09/07/2019	09/07/2019	1	339U7

Columns Position Check.

Notes:

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab.
 Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1") Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.

Columns Position Check Plan enclosed?	3. Circle each correct dimension with green colour. Circle each incorrect dimension with lea colour and mention ac
√Yes □No	III WILL LEG COLOUI ALL INEILION ACTUAL GITTEINSTON HEXT TO IT.

Slab Dimensions Check.

- 1. Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
- Show outer dimensions of slab. (Tolerance 2")
 Show length and width of balconies (Tolerance 1")
- Show inner dimensions of ducts and lift well. (Tolerance 1")
- Show location of sunken slab.
- Print an A3 size plan.
- 2. Sla Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it.

			The state of the s
611	Actual thickness of slab?	ار کی ا	Specified thickness of slab?
	✓ Yes □ No	losed?	Slab Dimensions Check Plan enclosed?

Quality Control Check Repot. Stage: After Column Casting (villas) Quality of centering, rod bending and concreting.

Good Avg. Bad
Good Avg. Bad
] High Medium. [] Low
Good Avg. Bad
1
¥Yes □ No
✓ Avg. ☐ Bad

Columns height, plumb, steel & level marking check. Notes:

- Mark o for correct or minor mistake which does not require correction
 Mark X for minor mistake that requires minor correction.
 Mark X for major mistake that requires correction by replacement or re-fixing.
 Mark X X for major mistake that cannot be corrected.
 Tolerance: Plumb 0.25".
 Circle actual height of columns if level differs from specified height by more than 1".

☐ Yes ☐ No										20.
☐ Yes ☐ No										19.
☐ Yes ☐ No										18.
☐ Yes ☐ No										17.
Yes No	<	<_	(<	<	81.11/2	81.12	Cr	•	16.
Yes No	<	<	<	<	<	81.11	81. 1/2"	C3	Į	15.
Yes No	<	<	<	V	<	91.212	8'. 14º	C3	سنفييي	14.
Yes No	5	*	5	<	<	81.24	8. 11/2 V	03	Ì	13.
Yes No	<		5	<	<	81.124	81 1/2"	C3	1	12.
Yes No	<	<	<	<	<	81.2"	8. 1 1/24	<u>۲</u>	1	11.
✓ Yes No	5	5	<	<	<	81. 1 /211	8'. 1/2"	C4	1	10.
Yes No	<	5	`	<	<	Q'. 1/2"	81. 142	٤)	g) comment	9.
Yes No	<	<	<	<	<	8.1024	81.101/21	CZ	~	8.
Yes No	<	5	<	, <	\	81.11	81.11/2"	(3	9	7.
✓Yes □No	<	۲.	<	5	<	81.1	81.1121	(3	1	6.
Yes No	<	<	<	<	<	8.11/2"	81.1 1/2"	C3	Brown	5.
V Yes □ No	7	<	V _	ľ.	~	8.211	8'. 11/2"	(3	· Parameter	4.
Yes No	K ,	1	V	<	<	8.11/20	81.121	3	3	3.
Yes No	~	-	<	V	V	8.11/20	81.11/21	C3	· Parameter in the second seco	2.
Yes No	V	1	4	~	4	81.10"	2, 10,7	C1	i i i i i i i i i i i i i i i i i i i	
marked on column?	Side 2	Side 1		Size of rods	No of rods	Actual	Spec.			
Reference level	Plumb (or x)	Plumb	Honeycombs	Steel (v or x)	Steel (t in ft	Height in ft	Col type	Col No.	S No