Quality Control Check Repot. Stage: After Column Casting (villas)

	lab?	Actual thickness of slab?		of slab?	Specified thickness of slab?
		Yes No		eck Plan enclosed?	at
next to it.	nention actual dimension	ion with red colour and r	e. Print an A3 size plan. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it.	3 size plan. dimension with green colou	 e. Print an A3 size plan. Circle each correct dimension
			ft well. (Tolerance 1")	Show length and width of balcomes (10 refaire 17) Show inner dimensions of ducts and lift well. (Tolerance 1") Show location of sunken slab.	b. Show lengthc. Show innerd. Show locate
			ck Plan as follows: ance 2")	es: Prepare Slab (or plinth beams) Dimensions Check Plan as follows: a. Show outer dimensions of slab. (Tolerance 2") i. Tolerance 1")	Notes: 1. Prepare Slab (or plir a. Show outer
				eck.	Slab Dimensions Check.
		Yes No		heck Plan enclosed?	Columns Position Check Plan enclosed?
next to it.	nention actual dinnension	ion with red colour and n	e. Print an A3 size plan. Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it.	size plan. dimension with green colour	 e. Print an A3 size plan. 3. Circle each correct dimension
			rance 1.5")	Show inner—inner space between columns. (1 oreface 1.7) Show diagonals for 20% of bays. (Tolerance 1.5")	c. Show inner d. Show diago
			(Tolerance 0.5")	Show size and orientation of columns. (Tolerance 0.5")	
			s:	Prepare Columns Position Check Plan as follows: a Divide blocks into smaller sub-blocks.	 Prepare Columns Po a Divide bloc
	each slab.	urting centering works for	es: Inspection should be done after casting of columns at each stage and before starting centering works for each slab	e done after casting of colun	Notes: 1. Inspection should be
				heck.	Columns Position Check
		,	uired.	Proceed with further work. ATR not required.	Proceed with furt
	ATR not required.	QC report to QC team out in the QC report.	Stop further work. Submit AIK on College, to College Canal Induced Canal Stop further work. Proceed with work after submitting ATR on QC report to QC team. The cond with further work only after making corrections pointed out in the QC report. A		Stop further work. Stop further work.
	by OC.	d only after recheck	Salamit ATP on OC report to OC team. Proceed only after recheck by OC		Recommendation:
☐ Yes ☐ No	For filling		MD Sign		Checked By MD on
11 L		Report filed and signed	34055	t no.	Previous stage report no.
10/08/19	Date	CLU	Sign	Kiran	Project Manager
	Date	i. Yunga Kumal	Sign	T. Vinad Kumax	Prepared by
X	Phase	90V	Project	Sov(LLP)	Company
34/69	SI. No.	0	Column No.	30	Block No.
٠,	01 11	•			

Quality Control Check Repot. Stage: After Column Casting (villas)

Ouglity of centering rod bending and concreting.]
Quality of centering, rod bending and concreting?	☐ G000	Good Avg. Bad
Quality of starters?	マ [´] Gooc	√Good Avg. Bad
Number and size of honey combs?	□High	High Medium. Low
Are the honey combs is slab and columns packed?	☐ G000	Good ☑'Avg. ☐ Bad
Number of beams that are sagging, bulging, caved or deflected in the slab by more than	han 1"	8 P P P
Have 6 cubes each for columns and slab casted and numbered for testing?	☑ Yes ☐ No	No
Remarks:		
Curing.		
Bunds for curing made on slab?	Yes LINO	
Bund size is less than 100 sft?	Yes No	
Drum (200 lts) provided for curing?	☐ Yes ☐ No	
?	Yes No	
Distance of tap from furthest distance that requires curing. (max permitted 100')	30011	
Frequency of curing in number of times a day (enquire from labourers)	2 times	
Is the pressure in the curing pipe more than 15' head?	∑Yes □No	
Quality of infrastructure for curing.	Good Avg. Bad	
Remarks:		

Columns height, plumb, steel & level marking check.

Notes:

- Mark v for correct or minor mistake which does not require correction
 Mark X for minor mistake that requires minor correction.
 Mark XX for major mistake that requires correction by replacement or re-lixing.
 Mark XXX for major mistake that cannot be corrected.
 Tolerance: Plumb 0.25".

SNO	Col No.	урс урс	Height Spec. Spec. 10 0	Height in ft . Actual . O'' 61-6'' 7'' 51-6'' 7'' 51-6'' 7'' 51-7'' 5-7'' 5-7'' 5-7'' 5-7'' 5-7'' 5-7'' 5-7''	Steel (No of rods	Steel (or x) of Size of is rods v v v v v v v v v v v v v	Honeycombs	Plumb of Side 1	Plumb (• or *) de 1 Side 2	Reference level marked on column? Yes _\No
9.			112-13	star	< <	۲. ۲.	< <	< <	< <.	
11.			1,4-19	1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1	55	۲. ۲.	ζ, ζ,	< <	< <	Yes No
13. 14.		2 3	114-13	1-120	ζ ζ	< < ,	< <	< <	<. <	Yes No
15.										Yes No
16. 17.										Yes No
18.										
19.										
20.							,			Yes No