P	b? 1 1 1/2	Actual thickness of sla	4 1/2"	lab?	Specified thickness of slab?
5 9		Yes No		c Plan enclosed?	Slab Dimensions Check Plan enclosed?
ext to it.	ntion actual dimension r	<ul> <li>b. Show length and width of balconies (Tolerance 1")</li> <li>c. Show inner dimensions of ducts and lift well. (Tolerance 1")</li> <li>d. Show location of sunken slab.</li> <li>e. Print an A3 size plan.</li> <li>Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it.</li> </ul>	erance 1") well. (Tolerance 1")  Zircle each incorrect dimen	Show length and width of balconies (Tolerance 1") Show inner dimensions of ducts and lift well. (Tolerance 1") Show location of sunken slab. Print an A3 size plan. ch correct dimension with green colour. Circle each incorrect	b. Show length and wid c. Show inner dimensio d. Show location of sun e. Print an A3 size plan.  2. Circle each correct dimension
			: Plan as follows:	<u>b Dimensions Check.</u> es:  Prepare Slab (or plinth beams) Dimensions Check Plan as follows:  a. Show outer dimensions of slab (Tolerance 2")	Stab Dimensions Check Notes:  1. Prepare Slab (or plinth b a. Show outer dim
		YYes No		ck Plan enclosed?	Columns Position Check Plan enclosed?
next to it.	ntion actual dimension	e. Frint an A3 size plan.  Circle each correct dimension with green colour. Circle each incorrect dimension with red colour and mention actual dimension next to it.	Circle each incorrect dime	ze plan. ension with green colour.	<ol> <li>Circle each correct dimension</li> </ol>
			uns. (Tolerance 1") ance 1.5")	Show inner – inner space between columns. (Tolerance 1") Show diagonals for 20% of bays. (Tolerance 1.5")	
			Tolerance 0.5")	<ul> <li>a. Divide blocks into smaller sub-blocks.</li> <li>b. Show size and orientation of columns. (Tolerance 0.5")</li> </ul>	a. b.
	each slab.	es: Inspection should be done after casting of columns at each stage and before starting centering works for each slab. Prenare Columns Position Cheek Plante & Flories.	ns at each stage and before	one after casting of column	Notes:  1. Inspection should be decided.
			双 37	ck.	Columns Position Check
	by QC. L ATR not required.	Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck l Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. Proceed with further work. ATR not required.	eport to QC team. Pro ter submitting ATR or cing corrections points uired.	Stop further work. Submit ATR on QC report Stop further work. Proceed with work after subproceed with further work only after making a Proceed with further work. ATR not required.	Stop further work.  Stop further work.  Proceed with further work.
☐ Yes ☐ No	For filling		MD Sign		Checked By MD on
NYes □No	d by PM?	Report filed and signed by PM?	11542	10.	Previous stage report no.
10/08/17	Date	Al	Sign	Kishirish kimen	Project Manager
41/80/04	Date	Pridy	Sign	P. Sai Limer	Prepared by
(	Phase	Bloomstake	Project	ENM	Company
94942	SI. No.	63	Column No.	75	Block No.

Quality Control Check Repot. Stage: After Column Casting (villas)

## Quality Control Check Repot. Stage: After Column Casting (villas)

Ouglity of centering rod hending and concreting	Transact.
Quality of centering, rod bending and concreting?	Good WAvg. Bad
Quality of starters?	Good Avg. Bad
Number and size of honey combs?	☐ High 【▼Medium. ☐ Low
Are the honey combs is slab and columns packed?	Good YAvg. Bad
Number of beams that are sagging, bulging, caved or deflected in the slab by more than 1"	1
Have 6 cubes each for columns and slab casted and numbered for testing?	√Yes □ No
Remarks:	
Curing.	•
Bunds for curing made on slab?	
Bund size is less than 100 sft?	
Drum (200 lts) provided for curing?	
Gunny bags used for column curing?	
Distance of tap from furthest distance that requires curing. (max permitted 100') 201.01	
Frequency of curing in number of times a day (enquire from labourers)	
ore than 15' head?	
Quality of infrastructure for curing.	Bad
Remarks:	

## **Quality Control Check Repot.** Stage: After Column Casting (villas)

## Columns height, plumb, steel & level marking check.

- Mark for correct or minor mistake which does not require correction
   Mark for minor mistake that requires minor correction.
   Mark x for major mistake that requires correction by replacement or re-fixing.
   Mark x for major mistake that cannot be corrected.
   Tolerance: Plumb 0.25".
   Circle actual height of columns if level differs from specified height by more than 1".

20.	19.	18.	17.	16.	15.	14.	13.	12.	11.	10.	9.	8.	7.	6.	5.	4.	က	2.	1.		SNo
						and the state of t						_				A	A.	<b>A</b>	F		Col No.
	300															63	C <b>5</b>	2	C5		Col type
																110.4	81.011	71.04	ت : :	Spec.	Heigi
								A American								(¢	31.0"	21.0"	4.16	Actual	Height in ft
								, and a second								<u> </u>	<u> </u>	<	5	No of rods	Steel (
									2000	39000000						<	\	<	\	Size of rods	Steel ( or x)
	:															<	\	<	<		Honeycombs
							sizair ke									Υ	~	<b>\</b>	7	Side 1	Plumb
			A													/	\	<	<	Side 2	Plumb (✓ or ×)
Yes No	☐Yes ☐No	□Yes □No	☐Yes ☐No	☐Yes ☐No	☐Yes ☐No	☐ Yes ☐ No	☐ Yes ☐ No	☐ Yes ☐ No	∏Yes ∏No	☐ Yes ☐ No	☐Yes ☐No	☐Yes ☐No	☐Yes ☐No	☐ Yes ☐ No	☐Yes ☐No	☐Yes ☐ No	√Yes □No	□Xes □No	☐Yes ☐No	marked on column?	Reference level