Quality Control Check Repot. Stage: After Column Casting (villas)

Recommendation: Stop further work. Stop further work. Proceed with further Proceed with further work.	Checked By MD on	Previous stage report no.	Project Manager	Prepared by	Company	Block No.
commendation: Stop further work. Submit ATR on QC report Stop further work. Proceed with work after so Proceed with further work only after making of Proceed with further work. ATR not required.		10.	5. Purshotham	V Santieth	Salle	3
eport to QC team. Proc ter submitting ATR or cing corrections pointe nired.	MD Sign	3 3920	Sign	Sign	Project	Column No.
scommendation: Stop further work. Submit ATR on QC report to QC team. Proceed only after recheck by QC. Stop further work. Proceed with work after submitting ATR on QC report to QC team. Proceed with further work only after making corrections pointed out in the QC report. ATR n Proceed with further work. ATR not required.		Report filed and signed by PM?	- FOJU	sal Kall	Sev	C2
by QC. h. ATR not required.	For filling	ed by PM?	Date	Date	Phase	Sl. No.
	☐ Yes ☐ No	∑Yes □No	71967/19	18/07/19	X	34c13

Columns Position Check.

Notes:

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab. Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1")
- Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.

ect dimension with green colour. Circle each incorrec	sion with red colour and mention actual dimension next to it.
Columns Position Check Plan enclosed?	✓ Yes ☐ No

Slab Dimensions Check.

Notes:

- Prepare Slab (or plinth beams) Dimensions Check Plan as follows:
 a. Show outer dimensions of slab. (Tolerance 2")
 b. Show length and width of balconies (Tolerance 1")

- Show inner dimensions of ducts and lift well. (Tolerance 1")
- Show location of sunken slab.
- Print an A3 size plan.

Slab Dimensions Check Plan enclosed?	es
Specified thickness of slab? 5^{W} Actual thickness	Actual thickness of slab? 5 ¹¹

Quality Control Check Repot. Stage: After Column Casting (villas)

Ouality of centering, rod bending and concreting.	
Quality of centering, rod bending and concreting?	Good Avg. Bad
Quality of starters?	☐ Good [v] Avg. ☐ Bad
Number and size of honey combs?	☐ High ☑ Medium. ☐ Low
Are the honey combs is slab and columns packed?	☐ Good ☑ Avg. ☐ Bad
Number of beams that are sagging, bulging, caved or deflected in the slab by more than 1"	C. Company
Have 6 cubes each for columns and slab casted and numbered for testing?	√Yes □ No
Remarks:	
Curing.	
Bunds for curing made on slab? ✓ Yes No	
Bund size is less than 100 sft?	
Drum (200 lts) provided for curing? ☐ Yes ☐ No	
Gunny bags used for column curing?	
Distance of tap from furthest distance that requires curing. (max permitted 100')	
Frequency of curing in number of times a day (enquire from labourers)	
Is the pressure in the curing pipe more than 15' head? ✓ Yes ✓ No	
Quality of infrastructure for curing.	Bad
Remarks: Stain cosx Columnes Shuttering boxes not	Lerroyed.

こうしょうこうかん とうしている 大阪大阪大学を変えている こうかい

The second of th

Notes: Columns height, plumb, steel & level marking check.

- Mark v for correct or minor mistake which does not require correction
 Mark X for minor mistake that requires minor correction.
 Mark XX for major mistake that requires correction by replacement or re-fixing.
 Mark XXX for major mistake that cannot be corrected.
- Tolerance: Plumb 0.25".

Circle actual height of columns if level differs from specified height by more than 1".

20.	19.	18.	17.	16.	15.	14.	13.	12.		10.				0.).	4.	3.	2.	1.			S No
						5	C3	C	0		1	dilen	15.3	182	13	A4	A3	A2	·A			Col No.
						2	5	0	0	C2.	C	C	12		0.	()	(2	C2.	C4.			Col type
						nt-8	3-7-8	4-18	8-7"	1, 1-8	Stains	8-7"	Staus	8-4"	nt. ,8	\$ 1	8-4"	14-18	"t-18		Spec.	Heigh
						8-5"	8-54	8-6"	17-8	8-6"	Staiss	8-5"	Slains	8-411	8-1	81611	8. ¹ 34	8-3"	8-71		Actual	Height in ft
						4	<	۷,	5	<	Ž,	4	<	Ž,	<,		<		¥	rods	No of	Steel (
						<	5	<	<	<_	<	<	ح ر	_	<_	<		~	<	rods	Size of	Steel (or x)
						<	₹	<		\	1	<	(Property of the Property of t		<	<	/	< ,	<u> </u>			Honeycombs
						<u> </u>	<	<	~ \	<u> </u>	gris se	V	•	/	<	1	<	۷,	<u> </u>		Side 1	Plumb
						<	<	<	<	<u> </u>	E. danser	V	C	V	1	/	<	<	<		Side 2	Plumb (or ×)
☐ Yes ☐ No	☐ Yes ☐ No	☐Yes ☐No	☐Yes ☐No	☐ Yes ☐ No	☐ Yes ☐ No	Yes No	√ Yes □ No	√Yes □No	☐Yes ☐No	√Yes □ No	☐ Yes ☐ No	Yes No	☐ Yes ☐ No	∐Yes □No		☐Yes ☐No	√Yes □No	√Yes □ No	⊠Yes □ No	column?	marked on	Reference level

こことを満まるとうなっていること