	Quality Control Check Repor
	heck Repot.
	Stage: After Column Ca
	umn Casting (
,	villas)

Column No. St. Column No. C St. No. C C C	1					
pject Mily Phase Phase Phase Date A Phase Date For filling I Phase Date Dat	Block No.	- 38	Column No.	0	Sl. No.	20242
Date Date Political Proceed only after recheck by QC. corrections pointed out in the QC report. ATR not required.	Company		Project	ということ		
Date Corrections pointed out in the QC report. ATR not required.		P.Sel Kin	Sign	Polidy		12/5/17
Report filed and signed by PM? Sign For filling to QC tcam. Proceed only after recheck by QC. ubmitting ATR on QC report to QC team. corrections pointed out in the QC report. ATR not required.	Project Manager	12 of healthan	Sign	Robert	Date	41/5/21
To QC tcam. Proceed only after recheck by QC. ubmitting ATR on QC report to QC team. corrections pointed out in the QC report. ATR not required.	Previous stage report no	0.		Report filed and signo	d by PM?	WYes No
to QC tcam. Proceed only after recheck by QC. ubmitting ATR on QC report to QC team. corrections pointed out in the QC report. ATR not required.	Checked By MD on		MD Sign		For filling	☐ Yes ☐ No
	Recommendation: Stop further work. Stop further work. Proceed with further	Submit ATR on QC replaced with work after work only after making work. ATR not require	port to QC tcam. Proce er submitting ATR on on one corrections pointed red.	ed only after recheck b QC report to QC team. out in the QC report. A	y QC. TR not required.	

Notes:

- Inspection should be done after casting of columns at each stage and before starting centering works for each slab. Prepare Columns Position Check Plan as follows:
- Divide blocks into smaller sub-blocks.
- Show size and orientation of columns. (Tolerance 0.5")
- Show inner inner space between columns. (Tolerance 1")
- Show diagonals for 20% of bays. (Tolerance 1.5")
- Print an A3 size plan.

2	C_{C}	بب
b D	lum	Circ
iner	ns P	de ea
sion	ositi	ch co
s Check	on C	rrect
Dimensions Check.	heck	dime
	Pla	noisi
	n enc	₩ith
Ì	ns Position Check Plan enclosed?	green
	d?	colo
l		nole e
		in distribution
) Sorre
13		. Circle each correct dimension with green colour. Circle each incorrect dimension
		nonei
1	-CV:	25 11.
ĺ	es	10
		2
İ	Vo an	
	d IIIG	1
	i mention act	
	actual	1
	a di	
	insioi	
8	on next to	
	to It.	

Notes:

- 1. Prepare Slab (or plinth beams) Dimensions Check Plan as follows.
 a. Show outer dimensions of slab. (Tolerance 2")
- Show inner dimensions of ducts and lift well. (Tolerance 1") Show length and width of balconies (Tolerance 1")
- Show location of sunken slab.
- e. Print an A3 size plan.
 Circle each correct dimension with or
- SI:

Specified thickness of slab?	Slab Dimensions Check Plan enclosed?	2. Circle cach correct dimension with green colour. Circle each incorrect dimension with red colour and mention ac
Actual thickness of slab?		correct dimension with red colour and mention actual dimension next to it

Quality Control Check Repot. Stage: After Column Casting (villas)

the state of correct bulleting caved or deflected in the slab by more than 1"	
Have 6 cubes each for columns and slab casted and numbered for testing?	✓ Yes ☐ No
Remarks:	
Bunds for curing made on slab?)
Bund size is less than 100 sft?	}
Drum (200 lts) provided for curing?	
Gunny bags used for column curing?	
Distance of tap from furthest distance that requires curing. (max permitted 100')	
Frequency of curing in number of times a day (enquire from labourers)	
Is the pressure in the curing pipe more than 15' head?	
Quality of infrastructure for curing.	Bad
Remarks:	

Quality Control Check Repot. Stage: After Column Casting (villas)

Columns height, plumb, steel & level marking check. Notes:

- Mark ✓ for correct or minor mistake which does not require correction Mark X for minor mistake that requires minor correction.

 Mark XX for major mistake that requires correction by replacement or re-fixing. Mark XX for major mistake that cannot be corrected.

 Tolerance: Plumb 0.25".

Circle actual height of columns if level differs from specified height by more than 1".

	ſ	10 8	D18605 00	110000000000	1	20000								,	_			_	,			
20.	19.	18.	17.	16.	15.	14.	13.	12.	Ξ	10.	9.	.∞	7.	6.	5.	4.	3.	2.			7.00	SNO
						p6	Dч	70	D1	82	42	85	B3	B1	48	AR	PS.	DU	Ā			Col No.
						1.0	CI	CI	C1	CI	CI	CI	c1	CI	c1	CI	C I	C1	2		•	Col type
		de Sala				8.411	8.41	8-71-	1-4.8	71.4.8	8.41	8.411	8-711	8.71	8. 71.	81711	3114.8	8-11-18	214.8	,	Spec.	Heigl
		0.000 &				8,411	8.41	8. 7"	8,8,1	8.44	8,411	8.511		8.7,	8-8"	81.811	8,4,1	8.7"	8. P.		Actual	Height in ft
						<	<	\	. \	<	\	<	<	/	1	<	<	<	7	rods	No of	Steel (
						<	<	<	<	<	<	<	<	1	<	< <u>.</u>	<	<		rods	Size of	Steel (or x)
						<	<	<	/	><	`<		<	<	\	<	<	<	7		I	Honeycombs
						<	<		\		<	<	<	, <	`	<	7	7	<		Side 1	Plumb (
						<	<	<	<	\	′.		<	<	<	1			/		Side 2	lumb (✓ or 🗙)
☐ Yes ☐ No	Ycs No	☐ Yes ☐ No	☐ Yes ☐ No	☐ Yes ☐ No	☐ Yes ☐ No	Yes No	☐Yes ☐No	Myes □No	✓yes □No	√yes □No	NYes □No	Yes □No	□Yes □No	Yes No	✓ Yes □ No	√Yes □ No	□Xes □No	□Yes □ No	YYes No	column?	marked on	Reference level